



ANVÄNDARINSTRUKTION

Patientlyftvåg SLSC2 200kg/100g

På sidorna 2 och 3 finns den svenska användarhandledningen som innehåller det den vanliga användaren behöver känna till.

Vågen levereras med de tillbehör som är specificerat från början så att den passar till de liftar den ska användas till. Om dessa ska bytas rekommenderas att vågen skickas till leverantören eller att en utbildad person ansvarar för montaget.

I den senare delen av instruktionen finns en fullständig manual på engelska för den som vill veta mer.



Denna typ av våg kommer normalt alltid med monterade tillbehör och det är normalt bara att montera den på aktuell applikation.

Vid leverans medföljer den svenska användarinstruktionen, på 3 sidor och den engelska original instruktionen.

Vill Du kan Du ladda hem en fullständig instruktion på <http://www.vetek.se/Shop/Arts/Detail.aspx?artID=1659>

Display och knappar

Displayen har en LCD display med 5 bakgrundsbelysta 20 mm siffror



	Batterisymbol visar om batteriet behöver laddas.
	Visar att vågen är obelastad.
Net	Visar att vågen visar nettovärde.
PT	Interaktivt läge (parametrar / justeringsläge)
1 2	Justeringsläge 1=Nolläge, 2=Känslighetsjustering Vägningsläge 1=Mätområde 1, 2= Mätområde 2 i Multirangeläge.
Lb kg t g	Visar vikten när vågen hänger stabilt.

Det mest intressanta är fetmarkerat.

Vågen manövreras med 2 st knappar



och



Knappar	Kort tryckning	Lång tryckning (>10s)
Till	Till / Från	
Brutto/Netto	Brutto / Nettoval eller Tara och Nettovisning	Justera till noll (+/-2%)
Till + Brutto/Netto (omväxlande) +	Interaktivt läge	- - - -

Felmeddelanden

Det enda felmeddelande som är relevant för användaren är när symbolen för dåligt batteri är tänd. (Det finns flera men dom syns enbart i kalibreringsläge).


Batteribyte

Lossa skruven på högra gaveln. Tag ur hållaren och byt till nya alkaliska AA batterier.


Specifikation

Tyy		SLSC2
Noggrannhetsklass enl OIML R76		C2
Max antal skaldelar intervall	d1=e1 d2=e2	2000
Max kapacitet (E _{max})	Kg	2000
Max verifiering interval	g	100
Max last kortvarigt (E _L)	Kg	500
Max last till brottgäns (E _D)	Kg	1000
Display		5 siffror
Batteri		4 x AA batterier
Batteri livslängd (AA med 1600 mAh)	timmar	270
Batterispänning	V	3,6 – 6 V
Strömförbrukning i vägningsläge	mA	<6
Strömförbrukning i standby mode	mA	<0,001
Nominellt temperaturområde (B _T)	grader C	-10 till +40
Arbets temperaturområde (B _{tu})	grader C	-20 till +60
Lagring temperaturområde (B _{ti})	grader C	-40 till +85
Dimensioner	Mm	164 x 87 x 70
Egenvikt	Kg	Ca 0,7
Skyddsklas enligt DIN 40050 (IEC529)		IP54

Dimensioner



Components at disposal:



M12 gänga

Gaffel 14 mm

Krok

Ring

Content Page	
Safety instructions	5
1 Introduction and appropriate use	7
2 Information on verified scales	8
2.1 Initial verification	8
2.2 Using verified scales in legal-for-trade operation	8
2.3 Declarations of conformity	9
3 Operating the crane scale	10
3.1 Display and control functions	11
3.2 Initial activation	11
3.3 Activation	12
3.4 Deactivation	12
3.5 Gross / net selection and taring	12
3.6 Zeroing	13
3.7 Changing the unit (kg <--> Lb)	13
3.8 Automatic zero tracking	13
3.9 Monitoring functions	14
3.10 Display values (factory defaults)	14
4 Setup dialog	15
4.1 Basic scale settings	15
4.2 Scale adjustment (Calibration in a partial load range)	16
5 Standard dialog / extended standard dialog	18
5.1 Counting scale	19
5.2 Power Off + Amplifier Filter	20
5.3 Mean-value calculation (Internal Conversion rate)	21
5.4 Automatic filter selection (Fast SettLing)	21
5.5 Gravitational acceleration at the place of installation (Gravity at destination)	22
5.6 Zero on startup (Zero Setting)	23
6 Replacing the battery	23
7 Attaching load application parts	23
8 Error messages	24
9 Specifications	25
10 Dimensions	26
11 Gravitational acceleration factors	27

Safety instructions

In cases where a breakage would cause injury to persons or damage to equipment, the user must take appropriate safety measures (such as fall protection, overload protection, etc.). For safe and trouble-free operation, weighing modules must not only be correctly transported, stored, sited and installed but must also be carefully operated and maintained.

It is essential to comply with the relevant accident prevention regulations. In particular you should take into account the limit loads quoted in the specifications.

Use in accordance with the regulations

The SLS... crane scale is conceived for weighing applications. Use for any additional purpose shall be deemed to be **not** in accordance with the regulations.

In the interests of safety, the crane scale should only be operated as described in the Mounting Instructions. It is also essential to observe the appropriate legal and safety regulations for the application concerned during use. The same applies to the use of accessories.

The crane scale is not safety element within the meaning of its use as intended. Proper and safe operation of this crane scale requires proper transportation, correct storage, assembly and mounting and careful operation and maintenance.

In the case of legal for trade use, the national legal and safety regulations must be complied with.

General dangers due to non-observance of the safety instructions

The SLS... crane scale correspond to the state of the art and are fail-safe. The crane scale can give rise to residual dangers if they are inappropriately installed and operated by untrained personnel.

Everyone involved with the installation, commissioning, maintenance or repair of a crane scale must have read and understood the Mounting Instructions and in particular the technical safety instructions.

Residual dangers

The scope of supply and performance of the crane scale covers only a small area of weighing technology. In addition, equipment planners, installers and operators should plan, implement and respond to the safety engineering considerations of weighing technology in such a way as to minimise residual dangers. Prevailing regulations must be complied with at all times. There must be reference to the residual dangers connected with weighing technology.

In these mounting instructions residual dangers are pointed out using the following symbols:



Symbol: **DANGER**

Meaning: **Highest level of danger**

Warns of a **directly** dangerous situation in which failure to comply with safety requirements **will** lead to death or serious physical injury.



Symbol: **WARNING**

Meaning: **Possibly dangerous situation**

Warns of a **potentially** dangerous situation in which failure to comply with safety requirements **can** lead to death or serious physical injury.



Symbol: **ATTENTION**

Meaning: **Possibly dangerous situation**

Warns of a **potentially** dangerous situation in which failure to comply with safety requirements **could** lead to damage to property, slight or moderate physical injury.

Symbols indicating application notes and useful information:



Symbol: **NOTE**

Refers to the fact that important information is being given about the product or its use.



Symbol:

Meaning: **CE mark**

The CE mark signals a guarantee by the manufacturer that his product meets the requirements of the relevant EC directives.



Symbol:

Meaning: **Statutory marking requirements for waste disposal**

National and local regulations regarding the protection of the environment and recycling of raw materials require old equipment to be separated from regular domestic waste for disposal.

For more detailed information on disposal, please contact the local authorities or the dealer from whom you purchased the product.

Environmental conditions

In the context of your application, please note that all materials which release chlorine ions will attack all grades of stainless steel and their welding seams. In such cases the operator must take appropriate safety measures.

Prohibition of own conversions and modifications

The scale electronic unit must not be modified from the design or safety engineering point of view except with our express agreement. Any modification shall exclude all liability on our part for any damage resulting therefrom.

Qualified personnel

This weighing electronic is only to be installed by qualified personnel strictly in accordance with the technical data and with the safety rules and regulations which follow. It is also essential to observe the appropriate legal and safety regulations for the application concerned. The same applies to the use of accessories.

Qualified personnel means persons entrusted with the installation, fitting, commissioning and operation of the product who possess the appropriate qualifications for their function.

Accident prevention

Although the specified nominal capacity in the destructive range is several times the full scale value, the relevant accident prevention regulations from the trade associations must be taken into consideration.

1 Introduction and appropriate use

The SLS... crane scale is a non-automatic weighing instrument (NAWI).

The nominal (rated) load and the parameters relevant to calibration are specified on the identification plate on the back of the device.

The scale can be used in applications subject to mandatory calibration up to 2000d=e.

Power is supplied by 4 batteries (AA cells).

The scale has an LCD display and 3 push-buttons. One button is used to adjust the scale (hidden button) and in the case of applications subject to mandatory calibration, is sealed with a calibration seal. Partial load adjustment is also possible.

A counting scale function can be activated via the operator menu.

Special features:

- Operating voltage 3.6 ...6 V
- Adjustable digital filtering and scaling of the measurement signal
- Display value range monitoring
- Power fail safe parameter storage
- Zero balancing (± 2 % of full scale)
- Automatic zero tracking (gross / net value, 0.5 d/s, ± 2 %)
- Automatic zero on startup (± 2 %...± 20 % of full scale)
- Taring
- Gross / net selection
- kg <—> lbs selection (not legal for trade)
- Verification switch with calibration counter
- Automatic cut-off, adjustable (off, 30 s, 60 s)
- Counting scale function

2 Information on verified scales

2.1 Initial verification

The initial verification by HBM is documented on the scales by the following stickers:

- **Green M:** Initial verification has already been performed on this device
- **CE seal:**
 - CE: EC mark of conformity
 - 06: Year in which the initial verification was performed (here 2006)
 - 0109: As a nominated European Community station, registration number 01.02–04, HBM has been authorized by the Verification Directorate of the State of Hesse to perform initial verification.



- **HBM Sealing:**

During the initial verification, this seal is used to protect scales of Accuracy Class III from unauthorized influence being exerted on the metrological data.
If this seal is violated, the verification is no longer valid.
The scales may then no longer be used for legal-for-trade operation.



NOTE

So please check the state of this sealing mark on your scales!

2.2 Using verified scales in legal-for-trade operation

Type approval for verification only applies to non-automatic scales.
For automatic operation with or without additional devices built on, please observe the national standards applicable to the place of installation.

The national legal standards for legal-for-trade use must be observed whenever the scale has to be re-adjusted, for example following repair, if the seal is broken, etc.

2.3 Declarations of conformity

Scales for use in legal metrology:

Directive 90/384/EEC "Non-automatic weighing instruments" regulates the determination of mass in legal metrology.

It also regulates the performance of EC verification by the manufacturer, provided there is EC type approval and the manufacturer has been accredited for these activities as a station nominated by the Commission of the European Communities.

The above EC Directive, applicable in the harmonized European single market since 01.01.1993 and official recognition from the Verification Directorate of the State of Hesse in 10.02.2006 that the requisite quality management system is in place at HBM, are the legal basis for performing EC verification at HBM.

Re-verifications in Germany

The validity period for initially scales verified for use in the medical sector expires after the fourth calendar year and for other industrial applications on expiry of the next but one calendar year to the year indicated on the initial verification sticker. Re-verifications must be performed by a weights and measures officer or by a station authorized for this purpose. A re-verification performed in due time must be registered at the local weights and measures office or authorized station. Please observe any changes made by the legislators, where applicable.

Re-verifications elsewhere in Europe

The period of validity of verification complies with the national standards applicable to the country in which the scale is being used. For information about the currently applicable legal standards in your country, please contact your local weights and measures office.

3 Operating the crane scale

3.1 Display and control functions

The display is an LCD with numbers 20 mm high:



Fig.2.1: LCD display

Description of symbols:

	The battery symbol indicates that the battery needs to be changed
0	Gross value in the accurate zero range (± 0.25 d)
Net	Net measurement display
PT	Interactive mode (parameters / adjustment menu)
1 2	Adjustment mode: 1 =Zero balance, 2 =Sensitivity adjustment Weighing mode (for multi-range scale): 1 =Measuring range 1, 2 =Measuring range 2
Lb kg t g	The weight unit is displayed when the scale is at rest (standstill)

The scale is operated by means of two push-buttons:



Fig.2.2: Control push-buttons

The following scale functions are controlled by the push-buttons:

Push-button(s)	Short keypress (standard function)	Long keypress (>10 s)
ON	ON / OFF switch	kg <--> lbs selection (only when not legal for trade)
G/N	Gross / net selection or tare and net display	Set to zero (± 2 %)
ON + G/N (simultaneously) 	Interactive mode	---

In the interactive mode (setting up the scale), the function of the push-buttons are different. This is described in chapter 4 "Setup dialog" and chapter 5 "Standard dialog / extended standard dialog".

Hidden button for scale adjustment:

The scale has a hidden push-button (remove the left-hand cover of the housing), which is immobilized by the calibration seal for applications subject to mandatory calibration. This push-button is used to adjust the scale.




Fig.2.3: Hidden push-button (symbolic representation)

Also refer to the section on "Gravitational factor for the place of installation (**Gd**)"

3.3 Activation

The scale is ready to use about 10 seconds after it has been switched on. **Do not move the scale or load it during this time !**



Switch the scale on



Display segment test (~5 seconds)



then all segments go out (~2 seconds)



Automatic zeroing ¹⁾ (~3 seconds)



The scale is ready to use.

¹⁾ If the initial loading of the scale (tare) exceeds 20 % of the weighing range, automatic zeroing does **not** take place. In this case, taring must be performed manually (see the "Gross / net selection and taring" section).

3.4 Deactivation

Factory setting: auto off = off




Press the ON/OFF button to switch the scale off.


The factory default is for the unloaded scale not to switch itself off automatically after 60 seconds. In interactive mode (see "Power Off + Amplifier Filter") it is possible to modify the deactivation characteristic.

3.5 Gross / net selection and taring


When the scale is ready to use, add the weight to be tared (e.g. the sling, weight 6.7 kg).



The gross weight is displayed
(when the scale is at rest, the weight unit is displayed)




Taring




The scale zero setting is displayed

Press the G/N button again to toggle between the scale zero setting and the gross weight.


Add any additional weight for taring (e.g. weight 3.1 kg).



The gross weight is displayed
(when the scale is at rest (standstill), the weight unit is displayed)



Taring



The scale zero setting is displayed

The first time the G/N button is pressed, the current total (gross) weight is displayed. Press the G/N button again to tare. You can repeat this process any number of times until the maximum weighing range of the scale is reached.

When the scale is switched off, the tare weight is cleared.


3.6 Zeroing

Zeroing (G/N button, long keypress) is only performed when the scale is at rest (standstill) and unloaded. The gross value must be within $\pm 2\%$ of the nominal load of the scale.

3.7 Changing the unit (kg \leftrightarrow Lb)

> > > Only possible for scales not subject to mandatory calibration. < < <


When the scale is ready for use, press the ON button and keep it pressed for ~5 seconds



Unit **kg**



keep it pressed for ~5 seconds



Unit **Lb** (American pound)

Proceed in the same way to change from **Lb** to **kg**.

Whichever unit is set is retained even when the scale is switched off.

3.8 Automatic zero tracking



This function prevents the scale zero point drifting and is only performed when the scale is at rest and unloaded (gross or net value = 0 ± 0.5 d). The maximum zeroing range is $\pm 2\%$ of the nominal load of the scale.

Zero tracking is switched **off** at the factory (**Zt = 0**, see "Extended standard dialog").

3.9 Monitoring functions


Battery status



The batteries are flat and must be replaced !
(battery voltage < 4 V)

If the scales are not subject to mandatory calibration, they can still be used to weigh for some time after the battery symbol appears. But to avoid measurement errors, the batteries should be replaced immediately.

Standstill



The weight unit lights up when the scale is at rest (± 1 d/s).
e.g. 100,0 kg

Overload



Please keep to the nominal load for the scale
(see the identification plate on the back of the device)

Underload



Switch the scale off and then on again.



Overload / underload limits:

Settings	Underload	Overload
Standard	Gross < -120 %	Gross > 120 %
OIML	Gross < -5 %	Gross > MAX + 9 d
NTEP	Gross < -5 %	Gross > MAX + 5 %

The percentages relate to the relevant nominal load.

3.10 Display values (factory defaults)

The scale is set to the following display values for nominal load at the factory:


calibratable			
	SLSC2	SLSC2-MR	
Mode	Nominal load (E_{\max}) = 200 kg	Nominal load (E_{\max}) = 320 kg	
OIML / NTEP	200.0 kg Increment = 1 d (= 100 g)	Max 1	200 kg d1=e1=100 g
		Max 2	320 kg d2=e2=200 g
not calibratable			
	SLS		
Mode	Nominal load (E_{\max}) = 200 kg	Nominal load (E_{\max}) = 250 kg	
Standard	200.00 kg Increment = 10 g	250.0 kg Increment = 100 g	

4 Setup dialog


4.1 Basic scale settings

Nominal load, decimal point, unit / increment / range (1 or 2-range scale)

The scale has a hidden button (remove the left-hand cover of the housing), which is immobilized by the calibration seal for applications subject to mandatory calibration. This button is used to adjust the scale.



Keeping the G/N button pressed, operate the hidden button




¹⁾ With dual-range scales, the setting **rn** applies to the first range. The increment for the second range is automatically the next-highest level!

Examples: if the **rn** setting = **01**, the increment in the second range is **02**
 if the **rn** setting = **05**, the increment in the second range is **10**

The scale stays in the second range even if the value falls below the changeover point between the first and second ranges. It will only change back to the first range once the scale is fully unloaded.


²⁾ With single-range scales:



³⁾ Once the scale has changed over to the second range, it will stay there even if the value falls below the changeover point between the first and second ranges. It will only change back to the first range once the scale is fully unloaded.

4.2 Scale adjustment (Calibration in a partial load range)

The scale has a hidden button (remove the left-hand cover of the housing), which is immobilized by a calibration seal for versions subject to mandatory calibration. This button is used to adjust the scale with a calibration weight of $> 20\% \dots < 120\%$.



- 1) To bypass the time-consuming process of gradually adding weight during verification, it is possible to activate 10-fold resolution of the measured value to allow direct reading of the analog measurement error [$\text{tr} = 1$]. But this is only possible for nominal values ≤ 9999 d (4 digits on the display), as 10-fold resolution cannot be displayed if they are any larger. This setting is only used to simplify the verification process and cannot be stored. When the scale is switched off, this increased resolution is reset back to what it was. As access to the hidden button is protected by the verification seal, once verification is complete, this increased resolution can no longer be activated without destroying the seal.



- 2) Before activating **Legal for trade**, you must first make all the settings that can no longer be changed once **Lt = 1 or 2** (see "Extended standard dialog")!
- 3) The gravitational acceleration at the place of calibration (see also "Gravitational acceleration at the place of installation" = Extended standard dialog: **Gd Gravity at destination**).
- 4) The last calibration weight to be entered is displayed and can also be applied without being changed. In this situation, the following displays are not the same as in the example shown.
- 5) The partial load value can be entered in the range 20 % to 120 % of the nominal load. If the input value is outside this range, **Err: 1** is displayed and you exit the menu. The incorrect value is not applied. Use the hidden button to call the menu again. The nominal load is specified on the nameplate (MAX1 or MAX2 with a dual-range scale).



- 6) If the calibration weight has been forgotten, **Err: 1** is displayed and you exit the menu. The parameters previously set are not applied. The old setting is retained. Use the hidden button to call the menu again.

The scale does not switch off automatically if a menu is active.


Once the scale is adjusted, refit the cover on the left-hand side and immobilize with the calibration seal for versions subject to mandatory calibration.*)



NOTE

***) ...it is essential that the required settings have already been made in the standard dialog / extended standard dialog !!!**


5 Standard dialog / extended standard dialog



Activate interactive mode
(Parameter menu / adjustment menu)


Standard dialog:

(**Standard_Function**)



Keeping the G/N pressed for ~5 seconds activates the extended standard dialog

Extended standard dialog:



^{*}) In legal for trade mode (**Lt** = **1** or **2**, see "Legal for trade"), it is not possible to change the value for **Gd** in the extended standard dialog. Display only.

#) Factory setting


¹⁾ see Section 5.3 "Mean-value calculation (**I**nternal **C**onversion rate)"

5.1 Counting scale


(Standard dialog)

The counting scale function must be enabled for the following dialog (**CE=1**, see "Extended standard dialog")!

As the zero point of the scale is measured automatically, any tare load (e.g. container, pan, etc.) must have been added to the scale **before this dialog**.




Activate interactive mode




The zero point of the counting scale is measured **automatically** (the colon flashes during measurement). **Do not move the scale or modify the tare load during this time !**



Put on the reference.




Enter the piece number (1 ... 999, e.g. 050) manually via the **ON** button, confirm each flashing digit with the **G/N** button.



Once the third digit has been entered or confirmed, the reference weight is **automatically** measured (the colon flashes during measurement). **Do not move the scale or modify the load during this time !**

The scale then switches back to display mode.


Remove the reference.




Display when the counting scale is **unloaded**.

The dot on the right of the display indicates that the scale is at rest.

Possible error message:



Reference weight invalid



30 sec. no standstill

Possible causes:


1. The counting scale adjustment (**Ct:Adjustment**) was not performed properly or was not performed at all
 >> **Activate interactive mode again (CT_F) and perform Ct:Ad first.**
2. Scale not at rest when the zero point was measured
 >> **Repeat the process; do not move the scale or modify the tare load while the zero point is being measured !**
3. Reference weight too low (<0.25 e)
 >> **Repeat the process with a permissible reference weight (≥ 0.25 e)**

5.2 Power Off + Amplifier Filter


(standard dialog)

The following functions can also be changed / adapted at any time for scales that are verified / subject to mandatory calibration:


Power Off (OFF time / -characteristic) + **Amplifier Filter** (Filter setting)





Activate interactive mode




(Standard_Function)




Power Off



Amplifier Filter



End dialog,
the display switches to
weighing mode



PO = Power Off (OFF time / -characteristic)

PO=0: manual deactivation only (with the **ON/OFF** button)

PO=1: Automatic deactivation after 30 seconds (only when scale is unloaded)

PO=2: Automatic deactivation after 60 seconds (only when scale is unloaded)

The scale only switches off automatically when it is in weighing mode and unloaded (gross value < 2 % of the nominal load). The **ON/OFF** button can be used at any time in weighing mode to switch off the device.

AF = Amplifier Filter (Filter setting)

Transient response:

The SLS has automatic filter selection that shortens the settling time of the **AF** filter. If a change in the measured value exceeds a set threshold ¹⁾, **AF=1** operates first. After a settling time of about 250 ms, the filter set with **AF** is selected. Filter **AF=1** quickly sets the internal filter status variables to the current measured value. The filter selected by **AF** then needs less time to settle to this measured value.

The filter setting needs to be such that the measurement display is steady (standstill) for the particular application. The scale has 9 filter levels (0...8). The higher the filter level selected, the steadier the display – although if the load is unsteady, it also takes longer for the measured value to come to a standstill.

#) Factory setting

¹⁾ see "Automatic filter selection (**FL** = **F**ast **S**ett**L**ing)" = Extended standard dialog

5.3 Mean-value calculation (Internal Conversion rate)

(Extended standard dialog)

This function can be used in addition to the filter setting (see **AF** = **A**mplifier **F**ilter), to stabilize the measurement display.

IC	Internal sampling rate Measured values / sec.	Mean-value calculation over n measured values	Display rate Measured values / sec.
0	100	n = 0 (factory default *)	6
1	50	n = 2	6
2	25	n = 4	6
3	12	n = 8	6
4	6	n = 16	6
5	3	n = 32	3
6	1	n = 64	1

*) = mean value calculation deactivated

5.4 Automatic filter selection (**F**ast Sett**L**ing)

(Extended standard dialog)

The function FL can reduce the settling time, whichever filter is chosen, to ~ 2 s (=typical value). For automatic filter selection, a value from **00** ... **99** can be chosen. When **FL** = **00**, the function is deactivated. The factory default is **FL** = **40**.

The **FL** function sets the threshold for the automatic filter selection. The filter selected by **AF** then needs less time to settle to the measured value (standstill).

If the change between two measured values is greater than the set threshold, **AF** = **1** operates. After a settling time of 250 ms, the filter set with **AF** is selected.

Function :

If there is a sudden load change that exceeds the switching threshold, the selected filter is switched off and back on again once the load value is reached. The switching threshold set with **FL** changes when the filter switches.

Selection :

Before you select the suitable **FL** setting, choose the necessary filter levels for the particular application (see "**AF** = **A**mplifier **F**ilter"). You must deactivate **FL** for this (**FL** = **00**).

Procedure :

- 1 Deactivate fast settling (**FL** = **00**).
- 2 Select the filter. Adapt **AF** to the operating conditions with regard to the mechanical vibrations. Steady measurement display despite mechanical disturbance.
- 3 Select a switching threshold for fast settling. Read off the required switching threshold from the table and enter **FL** = **xx**.

Important :

If too low a switching threshold is selected, mechanical disturbances can, under certain circumstances, cause the filter to switch constantly (filter ON/OFF). As a result, the display will be extremely unsteady.




Fig. 4.1:: Switching threshold (FL) depending on the Filter Setting (AF)

The switching threshold (FL) must therefore be selected such that it is higher than the load caused by the vibrations of the test system. The self dynamics must not exceed the adjusted threshold.

5.5 Gravitational acceleration at the place of installation

(Extended standard dialog)

The **Gd** = **G**avity at **d**estination function is used to enter the gravitational acceleration at the place where the scale is installed. Together with the gravitational acceleration at the place of calibration (**GC**=**G**ravitation **C**alibration), a correction factor is determined to compensate for measurement error as a result of different gravitational accelerations.

Example:

Gravitational acceleration at the place of calibration (e.g. Darmstadt, $g = 9.81029$): **GC = 9.81029**
 Gravitational acceleration at the place of installation (e.g. Tokyo, $g = 9.7977$): **Gd = 9.79770**
 The correction factor from this example ($GC / Gd = 1.001285$) is used internally by the SLS and ensures that the correct weight is displayed at the place where the scale is installed.

Notes:

- In the extended standard dialog, the gravitational acceleration factor **Gd** only has to be entered if the gravitational acceleration at the place of calibration and at the place where the scale is installed are different.
- The value for **Gd** is automatically (re)set to the value entered under **GC**,
 - when the scale is readjusted (see "Scale adjustment")
 - when **GC** is re-entered or modified
- In legal for trade mode (**Lt** = **1** or **2**, see "**L**egal for **t**rade"), it is not possible to change the value for **Gd** in the extended standard dialog.
- When setting up the scale at the place of installation, there is only one opportunity to enter **Gd** without affecting the legal-for-trade counter (also refer to "Initial activation").
- When the gravitational factor at the place of installation is known, it can be entered at the factory, before the scale is delivered. In this situation, the "Initial activation" section is not relevant and the scale is started up as described under "Activation".

5.

6 Zero on startup (Zero Setting)

(Extended standard dialog)

In legal for trade mode (**Lt** = **1** or **2**, see "**Legal for trade**"), it is not possible to change the value for **ZS** in the extended standard dialog.

Ranges for automatic zeroing after activating the scale:

ZS = 0	The function is deactivated
ZS = 1	Zeroing range $\pm 2\%$ ¹⁾
ZS = 2	Zeroing range $\pm 5\%$ ¹⁾
ZS = 3	Zeroing range $\pm 10\%$ ¹⁾
ZS = 4	Zeroing range $\pm 20\%$ ¹⁾

If there is no standstill or if the gross value falls outside the selected limits, zero is not set. If the gross value at standstill falls within the selected range, the gross value is accepted into the zero memory.

Scale standstill is fixed at 1 d/s.

¹⁾ of the nominal value of the scale

6 Replacing the battery

If the battery symbol is visible in the display, the batteries should be replaced as soon as possible.

Remove the right-hand cover (unscrew to release) to gain access to the battery holder for the 4 AA cells. Make sure that the batteries are inserted into the holder correctly (see the drawing inside the right-hand cover of the scale housing).

Flat batteries must not remain in the device and must be disposed in accordance with local regulations.

7 Attaching load application parts







The crane scale must be suspended by suitable components in such a way that its measurement shaft can automatically align to the center of the earth without moment.

This is achieved by using components that can move in all directions, so-called "universal joints", that must be attached above and below the scale. These parts must swivel freely at extremely low-friction without any noticeable "stick-slip effect", in a range of at least 5°.

The mechanical construction of the load application parts used in the scale has not been designed for the transfer of torsional moments in the axial direction. If such moments cannot be avoided when using the scale, these must be absorbed by means of appropriate additional swivel bearings in the lifter construction.

In addition to this, the manufacturer of the patient lifter or the operator of the scale must ensure that the system can carry safely and is stable under load. It is essential to comply with the relevant standards and guidelines for use.

8 Error messages


Display	Comment
	<p>Scale adjustment:</p> <ol style="list-style-type: none"> 1. The value entered for the calibration weight is incorrect: 20 % to 120 % of the nominal load of the scale 2. Incorrect or no calibration weight put on <ul style="list-style-type: none"> • Exit the dialog and re-perform the scale adjustment
	<p>Counting scale:</p> <ol style="list-style-type: none"> 1. The counting scale adjustment (Ct:Ad adjustment) was not performed properly or was not performed at all 2. Scale not at rest when the zero point was measured 3. Reference weight too low ($< 0.25\text{ e}$) <ul style="list-style-type: none"> • Activate interactive mode (Ct_F) again and perform Ct:Ad first. • Repeat the process; do not move the scale or modify the tare load while the zero point is being measured ! • Repeat the process with a permissible reference weight ($\geq 0.25\text{ e}$)
	<p>Counting scale:</p> <ol style="list-style-type: none"> 1. No standstill while the zero point is measured.
	<ul style="list-style-type: none"> • Replace the battery
Negative display when the scale is unloaded	<ul style="list-style-type: none"> • Run set to zero (see "Set to zero") or • Tare (see "Gross / net selection and taring")
	<ul style="list-style-type: none"> • Scale overloaded > Remove weight or • Perform scale adjustment
	<ul style="list-style-type: none"> • Switch the scale off and then on again or • Perform scale adjustment
No standstill (weight unit not visible / the counting scale dot not visible)	<ul style="list-style-type: none"> • Increase the filter setting and / or • avoid mechanical vibrations at the place of installation

9 Specifications

Type		SLS	SLS	SLSC2	SLSC2-MR
Accuracy class according to OIML R76		–	–	C2	C2/C1,6
Maximum number of scale intervals	$d_1=e_1$ $d_2=e_2$	20 000	2500	2000	2000 1600
Maximum capacity (E_{max}) Max 1 Max 2	kg	200	250	200	200 320
Minimum verification interval e_1 e_2	g	10	100	100	100 200
Safe load limit (E_L)	kg	500			
Breaking load (E_d)	kg	1000			
Display		5 digits			
Battery		4 x AA cells			
Battery life (AA cell with 1600 mAh)	h	270			
Battery voltage	V	3.6 ... 6V			
Current consumption, active mode	mA	< 6			
Quiescent current, stand-by mode	mA	< 0.001			
Nominal temperature range (B_T)	°C [°F]	–10 ... +40 [+14 ... +104]			
Operating temperature range (B_{tu})	°C [°F]	–20 ... +60 [–4 ... +140]			
Storage temperature range (B_{tl})	°C [°F]	–40 ... +85 [–40 ... +185]			
Dimensions (W x H x D)	mm	164 x 87 x 70			
Weight	kg	approx. 0.7			
Protection class acc. to DIN 40050 (IEC529)		IP54			

The scale is not sensitive to HF irradiation and conducted interference in accordance with OIML R76, EN45501 and EN55011B (noise emission) and EN50082-2.

10 Dimensions



* The measurements will depend on the (customized) components being used

11 Gravitational acceleration factors

The parameters **GC** (**G**ravitation **C**alibration) and **Gd** (**C**alibration **d**estination) can take into account the different gravitational accelerations at the place where the scale is calibrated and the place where it is installed. The values apply to a height of 100 m above sea level.

(Source: Table: from IGSN71, factor gravitational acceleration in ms⁻²)

Europe

Location	Factor	Location	Factor
Darmstadt	9.81029	Madrid	9.7999
Hamburg	9.8137	Rome	9.8039
Stuttgart	9.8104	Milan	9.8055
Munich	9.8074	Marseilles	9.8048
Bergen	9.8195	Barcelona	9.8031
Oslo	9.8193	Valencia	9.8008
Stockholm	9.8182	Catania	9.8003
Copenhagen	9.8155	Seville	9.7988
London	9.8120	Malaga	9.7995
Paris	9.8096	Bordeaux	9.8060

Asia, Africa

Location	Factor	Location	Factor
Beirut	9.7968	Casablanca	9.7963
Tehran	9.7940	Cairo	9.7929
Tokyo	9.7977	Accra	9.7808
Delhi	9.7912	Addis Abeba	9.7745
Hong Kong	9.7876	Nairobi	9.7753
Aden	9.7831	Kinshasa	9.7793
Bangkok	9.7831	Salisbury	9.7812
Manila	9.7835	Cape Town	9.7963
Colombo	9.7812		
Singapore	9.78065	Arctic, Antarctic	9.82492

America

Location	Factor	Location	Factor
Vancouver	9.8092	Mexico City	9.7794
Winnipeg	9.9098	Panama	9.7823
Montreal	9.8063	Bogota	9.7739
Denver	9.7961	Lima	9.7829
Chicago	9.8027	Belem	9.7802
Washington	9.8009	Rio de Janeiro	9.7876
San Francisco	9.7997	Buenos Aires	9.7970
Houston	9.7928	Central America	9.78835
Miami	9.7902	USA (South)	9.79496
Anchorage	9.8191	USA (North)	9.80269

Australia, Oceania

Location	Factor	Location	Factor
Darwin	9.78301	Melbourne	9.7995
Perth	9.7940	Wellington	9.8027
Alice Springs	9.7865		
Brisbane	9.7914	Oahu - Honolulu	9.7893

If the location is not listed in the tables, use the following equation to calculate the gravitational acceleration value:

$$g = 9.780318 * (1 + 0.0053024 * \sin^2(br) - 0.0000058 * \sin^2(2 * br)) - 0.000003085 * h$$

g = gravitational acceleration [m/s²]

br = degree of latitude for the location [degrees]

h = height above sea level [m]

Note: Conversion br [rad] = $\pi * br$ [degree of angle] / 180

This equation is valid for Class III scales (≤ 3000 d).