




DFW • DFWL

TECHNICAL MANUAL - v5

ENGLISH



CONTENTS

1. Introduction and warnings	4
2. Technical features	4
3. Approval.....	5
4. Connections	6
Single channel	6
Multichannel.....	7
5. Programming.....	8
How to access the programming menu.....	8
How to save the programming and exit the menu	8
Programming menu	9
6. Communication strings.....	41
7. Communication controls	42
8. Wiring schemes	44
DFWLxxx, WLB, TPWNxxx, TPWLxxx, MCWNxxx.....	44
DFWLIDxxx.....	44
DFWxxx, TPWxxx, MCWxxx.....	45
9. Programming errors	46
10. FAQ - Frequently Asked Questions	47
11. Summary of the parameters	48

CONTENTS BY TOPIC

Calibration

Quick calibration	10
Complete calibration	37

Equalisation

Multichannel connection	7
Equalisation procedure.....	36

Safety

Protection of the configuration menu via PIN.....	40
Protection of the user menu via PIN	40

Communication

Configuration of the serial port for PC.....	12
Configuration of the serial port for printer	14
Wiring schemes.....	44
Communication strings.....	41
Communication controls	42

Approval

Approval seal.....	5
Display of the metrological version.....	5

Reset

Factory configuration reset	33
Complete reset of memory	40

1. INTRODUCTION AND WARNINGS

This product represents the best solution for multi-function weighing applications, offering ease of use, high precision in reading the weight and many functions to speed-up and simplify everyday work.

This manual provides an overview of the product's potentials: through the configuration menu, you can adapt the product functionality to the weighing application to be realised.



WARNINGS:

- Do not make repairs or replace electronic components of the instrument boards.
- Only use original spare parts.
- Any tampering with the equipment or use of non-original spare parts voids the warranty and relieves the manufacturer of any liability.
- Before any installation or repair that involves access to electronic parts, turn off the device and disconnect any source of power supply (battery, 230V network or other).
- Always use network power supply sources regulated within $\pm 10\%$ of the rated voltage;
- In applications in connection with third parties, always follow the specifications given on the approval decree of the equipment.
- Do not immerse in water.
- Do not wash with water jets (except versions with specific IP protection degree).
- Protect from direct rainfall (except versions with specific IP protection degree).
- Do not use aggressive cleaning solvents or substances.
- Do not install in potentially explosive environments.
- Earth connect any earth socket located on the equipment casing, using a cable with a diameter of at least 16 mm².


2. TECHNICAL FEATURES

Power supply via mains / Battery charger	110-230Vac	
MAX consumption	5W	
Analog channels for reading of load cells	4	
Managed / displayed scales	1	
Connectable cells	8 da 350 Ohm	
Load cells power supply	5V	
Maximum load cells power supply current	120mA	
Maximum operating temperature range CE-M - OIML	-10°C + 40°C	
Maximum operating temperature range	-10°C + 60°C LCD/-20°C + 60°C LED	
OIML divisions	10000e 3x3000e	
Divisions for internal use	100d ... 1.000.000d	
Optional Digital relays (only for DFW family)	Number	2 / 4
	Features	48 Vac, 60 Vdc, 15 mA, 10 Ω Max
Optional Digital inputs (only for DFW family)	Number	2 / 4
	Features	12 / 24 Vdc, 5:20 mA
Optional analog output (only for DFW family)	0:10 Vdc, 0:20 mA	
Serial ports	2	




3. APPROVAL


a.




b.




c.



d.




e.




How to display the metrological version of the instrument




1. Turn off the scale



2. Follow the procedure:




4. CONNECTIONS



Single channel



Connect the scale to the main terminal board using the first reading channel of the A/D converter.



Terminal board of reference for connection to 1 channel


NOTES:


- For connection with 6 wires with "Sense", remove jumpers J2 and J3.
- For connection with 4 wires, install jumpers J2 and J3.



WARNING:

Make the connections with indicator off and feeder disconnected. Comply with the electronic specifications indicated in the table on page 4





Multichannel with digital equalisation




You can use the 4 channels of the converter to connect 2, 3 or 4 cells, digitally equalising them without using junction boxes.

Terminal boards of reference for connection to 4 channels

NOTES:

- Install jumpers J2 and J3.




5. PROGRAMMING


How to access the programming menu



1. Turn off the scale



2. Follow the procedure:




How to save the programming and exit the menu



To save the programming changes made, repeatedly press the key browsing the menu in reverse, until the message **SAUEP** appears: press to save or to exit without saving.

Example (*read from right to left*):



⚙️ PROGRAMMING MENU

 CAL	Quick calibration.....	10
 D.CAL	Reset of Pre-Tare (zero calibration).....	11
 GrAU	Area of gravity of the place of use.....	11
 SERIAL	Configuration of the serial ports.....	12
 LAYOUT	Print customisation.....	17
 FILTER	Weighing filter.....	25
 SCREEN	Adjusting the display.....	26
 bATT	Using the battery.....	27
 ECO.bATT	Energy saving.....	27
 AutoFF	Auto off.....	28
 rEMOTE	Using the remote control.....	28
 An.out	Analog output.....	29
 inPutS	Digital inputs.....	31
 outPut	Digital outputs.....	32
 rESEt	Factory configuration reset.....	33
 d.iAG	Diagnostics.....	33
 AdVAnc	Advanced.....	34

 Parameter visible only in certain conditions.



Parameter or menu subject to approval.





MENU

How to enter

1. Off
2. On
- 3.
- Page 8


How to browse

- =
- =
- =
- =

How to save and exit



Page 8




CAL Quick calibration



Start of the calibration procedure:

A-1



Set the division and press

How to set the value



CALPAC **000.000**



How to set the value



000.000

Enter the calibration weight and press

How to set the value



CAL.oF

If an advanced calibration (e.g. multi range) has been already stored, the **CAL** step jumps to the **Q-1**, **Q-2** and **Q-3** step (see page 34).



MENU

How to enter

1. Off
2. On
- 3.
- Page 8

How to browse

- | | |
|--------|---|
| = | = |
| = | = |
| Page 8 | |


How to save and exit

**A** **B** **C** **D** **E** **F** **G** **H** **I** **J** **K** **L** **M** **N** **O** **P** **Q**

D.CAL Reset of the Pre-Tare



Acquisition of the zero point



GrAU Area of gravity of the place of use



Once the calibration is completed, for proper operation set the area of use in this pitch (if different from that of calibration).



Area of gravity
(9.75001...9.84999)

How to set the value





MENU

How to enter

1. Off
2. On
- 3.
- Page 8


How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8




SERIAL Configuration of the serial ports



CoN.PC Communication with PC, PLC or Repeater

Selection of the communication mode



* For communication strings and controls, see page 41 - 42.

For the string selection, see step **D-3-1**.



MENU

How to enter

1. Off
2. On
- 3.
- (i)* Page 8

How to browse

- =
- =
- =
- =

How to save and exit



(i) Page 8

A

B

C

D

E

1

F

2

1

G

3

2

H

3

I

4

J

K

L

M

N

O

P

Q

Selecting the COM port for connection with PC/PLC

D-1-2

Communication speed (Baud rate)

D-1-3

1200

9600

115200

Configuration of the serial protocol

D-1-4





MENU

How to enter

1. Off
2. On
- 3.
- (i)* Page 8

How to browse

- ↑ =
 ↓ =
 → =
 ← =

How to save and exit



(i) Page 8

A **CAL**

B **D.CAL**

C **GrAU**

D **SERIAL**

E **LAYOUT**

1 **CoN.PC**

F **FILEEr**

2 **CoN.Prn**

G **SCREEn**

3 **AdUAnC**

H **bAtt**

1 **NodE**

I **ECOBAt**

2 **bAud**

J **AutoOFF**

3 **b.iE**

K **rENote**

4 **Cts**

L **An.out**

5 **PoWER.P**

M **inPutS**

N **outPut**

O **rESEt**

P **d.iAG**


Q **AdUAnC**

SERIAL Configuration of the serial ports

CoN.Prn Communication with printer or repeater or PC




Selection of the communication mode




(i) For communication strings and controls, see page 41 - 42.

Communication speed (Baud rate)




MENU


How to enter	How to browse	How to save and exit
1. Off	↑ =	How to save and exit
2. On	↓ =	
3.	→ =	
Page 8	← =	Page 8




Configuration of the serial protocol



Printer control signal



Printer power supply / Radio-frequency module



Printer power supply from indicator via Vaux connector.
Visible only in modules equipped with Vaux, ref. Wiring schemes (see page 44).



MENU

How to enter

1. Off
2. On
- 3.
- (i)* Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



(i) Page 8

A

B

C

D

E

1

F

2

G

3

H

1

I

2

J

3

K

4

L

M

N

O

P


Q

SEr iRL Configuration of the serial ports

AdUARnC Advanced configurations




Communication protocol




(i) For communication strings and controls, see page 41 - 42.

Connection port of radio-frequency module (for use by the manufacturer)




* Selection of the radio channel.

TTL port / Inclinometer activation (for use by the manufacturer)



Only for DFWL models.

Closing character of each print line





MENU

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 8	← =	


- A
- B
- C
- D
- E **LAyout** →
 - F 1
 - G 2
 - H 3
 - I 4
 - J 5
 - K 6
 - L 7
 - M 8
 - N 9
 - O 10
 - P 11
 - Q 12
 - 13
 - 14
 - 15
 - 16
 - 17
 - 18

LAyout Print customisation

Parameters for receipt/label mode



Additional parameters for label mode





MENU

How to enter

1. Off 
 2. On 
 3. 

How to browse

- ↑ = 
 ↓ = 
 → = 
 ← = 


How to save and exit



i Page 8



Setting of the print language (*itAL*, *EnGL*, *dEut*, *FrAn*, *ESPA*, *ChInES*)




Character dimensions




Main character

Label mode



Receipt mode



E-2-2

Char 2


See ChAr 1





MENU

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 8	← =	Page 8




LAYOUT Print customisation

hEAdEr Print header



Enables header printing

E-3-1 **EnAbLE**



Only 1st totalisation

Only upon each totalisation


Also in total

Contents of the header lines

E-3-2 **L.inE 1**

First row of header

Visible only in L.inE 2, L.inE 3 and L.inE 4



Enter the first character

Enter the second character

Enter the last character

How to set the value



(i) Repeat the operation to program L.inE 2, L.inE 3 and L.inE 4.
Select **no** to disable them.





MENU

How to enter

1. Off
2. On
- 3.
- Page 8

How to browse

- =
- =
- =
- =

How to save and exit



Page 8

A **CAL**

B **0.CAL**

C **GrAU**

D **SEr.iAL**

E **LAYOUT**

F **FILEEr** 1 **LAnG**

G **SCREEn** 2 **ChAr**

H **bAtt** 3 **hEAdEr**

I **ECo.bAt** 4 **dAtA** 1 **EnAbLE**

J **AutoOFF** 5 **BE.iCHS** 2 **L_inE 1**

K **rENote** 6 **E_iCREt** 3 **L_inE 2**

L **An.out** 7 **CLoCF** 4 **L_inE 3**

M **inPut5** 8 **bArC.39** 5 **L_inE 4**

N **outPut** 9 **bArC.uP**

O **rESEt** 10 **bArC.L**

P **d.iAG** 11 **bArC.h**

Q **AdUAnC** 12 **bArC.dt**

13 **CoP.iES**

14 **End.E.iC**

15 **bL.inE**

16 **LAbel**

17 **LB.SAUE**

18 **tESt**

How to print/delete the row being programmed

01 032

02 032

03 032

01 032

02 032

03 032

04 032

05 032

06 032

24 032

List of characters

(*)

32		47	/	62	>	77	M	92	\	107	k	122	z
33	!	48	0	63	?	78	N	93]	108	l	123	{
34	"	49	1	64	@	79	O	94	^	109	m	124	
35	#	50	2	65	A	80	P	95	_	110	n	125	}
36	\$	51	3	66	B	81	Q	96	'	111	o	126	~
37	%	52	4	67	C	82	R	97	a	112	p		
38	&	53	5	68	D	83	S	98	b	113	q		
39	'	54	6	69	E	84	T	99	c	114	r		
40	(55	7	70	F	85	U	100	d	115	s		
41)	56	8	71	G	86	V	101	e	116	t		
42	*	57	9	72	H	87	W	102	f	117	u		
43	+	58	:	73	I	88	X	103	g	118	v		
44	,	59	;	74	J	89	Y	104	h	119	w		
45	-	60	<	75	K	90	Z	105	i	120	x		
46	.	61	=	76	L	91	[106	j	121	y		


MENU

How to enter	How to browse	How to save and exit
1. Off	=	
2. On	=	
3.	=	
Page 8	=	Page 8


- A CAL
- B D.CAL
- C GrAU
- D SERIAL
- E LAYOUT
- F FILTER 1 LANU
- G SCREEN 2 Char
- H bAtt 3 hEAdEr
- I ECOBAT 4 dAtA
- J AutoOFF 5 BE iGHS
- K rENote 6 t iCReEt
- L An.out 7 CLoCH
- M inPutS 8 bArC.39
- N outPut 9 bArC.uP
- O rESEt 10 bArC.L
- P d.RG 11 bArC.h
- Q AdURanC 12 bArC.dt
- 13 CoP iES
- 14 End.t iC
- 15 b.L inE
- 16 LABEL
- 17 LB.SAUE
- 18 tESt




Selection of the weight data



Progressive weighed



Receipt/label progressive




MENU


How to enter	How to browse	How to save and exit
1. Off	=	
2. On	=	
3.	=	
Page 8	=	Page 8

- A **CAL**
- B **D.CAL**
- C **GrAU**
- D **SER.iAL**
- E **LAYOUT**
- F **FILEEr** 1 **LAND**
- G **SCREEN** 2 **ChAr**
- H **bAtt** 3 **hEAdEr**
- I **ECobAt** 4 **dAtA**
- J **AutoOFF** 5 **HE.iGHS**
- K **rENoteE** 6 **tICRET**
- L **An.out** 7 **CLOCK**
- M **inPutS** 8 **bArC.39**
- N **outPut** 9 **bArC.uP**
- O **rESEt** 10 **bArC.L**
- P **d.iAG** 11 **bArC.h**
- Q **AdUAnC** 12 **bArC.dt**
- 13 **CoP.iES**
- 14 **End.E.iC**
- 15 **b.L.inE**
- 16 **LAbEL**
- 17 **LB.SAUE**
- 18 **tESEt**

Date and time




Bar code 39




Barcode top margin (mm)

Visible only if **bArC.39** (E-8) is active




Barcode left margin (mm)

Visible only if **bArC.39** (E-8) is active



Barcode height (mm)

Visible only if **bArC.39** (E-8) is active



MENU


How to enter	How to browse	How to save and exit
1. Off	=	
2. On	=	
3.	=	
Page 8	=	Page 8

- A CAL
- B D.CAL
- C GrAU
- D SER.iAL
- E LAYOUT
- F FILEEr 1 LAnG
- G SCREEN 2 ChAr
- H bAtt 3 hERdEr
- I ECobAt 4 dAtA
- J AutoOFF 5 HE.iChS
- K rENote 6 E.iCREt
- L An.out 7 CLoCH
- M inPut5 8 bArC.39
- N outPut 9 bArC.uP
- O rESEt 10 bArC.L
- P d.iRG 11 bArC.h
- Q AdUARnC 12 bArC.dt
- 13 CoP.iES
- 14 End.t.iC
- 15 b.L.inE
- 16 LABEL
- 17 Lb.SAUE
- 18 tESt




Selection of the weight data


Visible only if (E-8) is active




Multi-copy prints



Paper outlet for end of label/receipt



White pre-heating line of the print head
(for thermal printer only)




MENU

How to enter	How to browse	How to save and exit
1. Off	=	
2. On	=	
3.	=	
Page 8	=	Page 8

- A CAL
- B D.CAL
- C GrAU
- D SER AL
- E LAYOUT
- F FILEEr 1 LAng
- G SCREEN 2 ChAr
- H bAtt 3 hEAdEr
- I ECobAt 4 dAtA
- J AutoFF 5 HE iGHS
- K rENote 6 E iCReEt
- L An.out 7 CLoCF
- M inPutS 8 bArC.39
- N outPut 9 bArC.uP
- O rESEt 10 bArC.L
- P d.iAG 11 bArC.h
- Q AdUAnC 12 bArC.dt
- 13 CoP iES
- 14 End.e iC
- 15 b.L inE
- 16 LAbeL
- 17 Lb.SAUE
- 18 tEST


Label configuration

Visible only if Node (D-2-1) = LABEL




Saving of labels in the printer memory

Visible only if Node (D-2-1) = LABEL



Saving of labels in the printer memory (for label mode only) and test print of ALL FORMATS





MENU

How to enter

1. Off
2. On
- 3.
- (i) Page 8*

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



(i) Page 8

A *CAL*

B *0.CAL*

C *GrAU*

D *SEr_AL*

E *LAYOUT*

F **Filter**

G *SCREEN* 1 **StAnd.0**

H *bAtt* ... 4 **StAnd.3**

I *ECobAtt* 5 **h_irE5.0**

J *AutoFF* ...

K *rENote* 12 **h_irE5.1**

L *An.out* 13 **dyn.0**

M *inPut5* ...

N *outPut* 16 **dyn.3**

O *rESEt* 17 **SLoB.0**

P *d_irG* ...

Q *AdUAnC* 20 **SLoB.3**

21 **do5.0**

... 24 **do5.3**

25 **r.AdC 0**

... 28 **r.AdC 5**

Filter Weighing filters



Edits scale reactivity.

Useful to adjust the scale to your needs.

With the approved instrument, you can select only some of the filters listed below (StAnd.0...3, h_irE5.0 - 1, dyn.0 - 1, SLoB.0 - 1).

To weigh live animals, you must also activate the additional filter *no SE* in *AdUAnC*.

Premise:

The "0" represents minor filtering incidence.

Increasing the incidence give the weight more stability.

We recommend weighing several times, changing the incidence until you obtain the best compromise between reactivity and stability.



Table and floor scales and piece counters

F-1 **StAnd.0**

...



F-4 **StAnd.3**



High precision scales

F-5 **h_irE5.0**


...



Suspended and oscillating load weighing

F-13 **dyn.0**


...




Liquid weighing, weighbridges and weighing with vibrations

F-17 **SLoB.0**

...





F-20 **SLoB.3**



Metering, filling, level check and overloads

F-21 **do5.0**

...



F-24 **do5.3**

Automatic

Manual

Filter for specific applications for use by the manufacturer

F-25 **r.AdC 0**

...

F-28 **r.AdC 5**





MENU

How to enter

1. Off
2. On
- 3.
- Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



Page 8

A

B

C

D

E

F

G

H 1

I 2

J 3

K 4

L

M

N

O

P

Q

SCREEn Adjusting the display

Backlighting

G-1

Always on

On when weight is unstable

Brightness

G-2

...

Display lock (for use by the manufacturer)

G-3

Backlighting colour

G-4

...

Only in version with colour display.



MENU

How to enter

1. Off
2. On
- 3.
- Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =


How to save and exit



Page 8

- A**
- B**
- C**
- D**
- E**
- F**
- G**
- H**
- I**
- J**
- K**
- L**
- M**
- N**
- O**
- P**
- Q**

bATT Power supply via battery



Only for DFWL models.


4 AA Batteries

Lead rechargeable battery

niMh rechargeable battery

WARNING:
only use original rechargeable batteries.

ECo.bAT Energy saving for battery operation



Visible only if bATT (H) is active

Maximum consumption, maximum reactivity

Reduced reactivity, reduced consumption

Reduced reactivity, reduced consumption

Minimum consumption. Scale in standby and power at the touch of a button and automatic switch-off at the end of weighing.



MENU

How to enter

1. Off 
 2. On 
 3. 

How to browse

- ↑ =
 ↓ =
 → =
 ← =


*How to save
and exit*




 Page 8

- A **CAL**
 - B **.CAL**
 - C **GrAU**
 - D **SEr.iAL**
 - E **LAyout**
 - F **FILEEr**
 - G **SCrEEEn**
 - H **bAtt**
 - I **ECo.bAT**
 - J **AutoFF**
 - K **rENote**
 - L **An.out**
 - M **inPutS**
 - N **outPut**
 - O **rESEt**
 - P **d.iAG**
 - Q **AdUARnC**

AutoFF Auto off



rENote Remote control



 The broadcast mode allows sending the control to multiple scales simultaneously.





MENU

How to enter

1. Off 
 2. On 
 3. 

How to browse

- ↑ = 
 ↓ = 
 → = 
 ← = 

How to save and exit



i Page 8


- A CAL
 - B DCAL
 - C GrAU
 - D SEr iAL
 - E LAYout
 - F FILEEr
 - G SCrEEn
 - H bAtt
 - I ECobAT
 - J AutoOFF
 - K rENote
 - L An.out
 - M inPut5 1 nEt
 - N outPut 2 Pnt.und
 - O rESEt 3 BGt.1
 - P d iAG 4 Pnt.1
 - Q AdURAnC 5 BGt.2
 -
 - 6 Pnt.2
 - 7 BGt.3
 - 8 Pnt.3
 - 9 Pnt.oUr

An.out Analog output



 *Visible only in the presence of optional analog board.*

Operation proportional to the net/gross weight



 Thanks to the real-time upgrading of the output, using a tester you can check the value entered (see example page 30).

Value to be entered	Output volts	Output mA
1200	~ 0 V	~ 0 mA
11250		~ 4 mA
52200		~ 20 mA
62300	~ 10 V	


MENU

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 8	← =	 Page 8


- A **CAL**
- B **D.CAL**
- C **GrAU**
- D **SERIAL**
- E **LAYOUT**
- F **FILTER**
- G **SCREEN**
- H **bATT**
- I **ECOBAT**
- J **AutoOFF**
- K **RENOTE**
- L **An.out**
- M **inPut5**
- 1 **nEt**
- N **outPut**
- 2 **Pnt und**
- O **rESEt**
- 3 **HGT.1**
- P **d.iAG**
- 4 **Pnt.1**
- Q **AdUAnC**
- 5 **HGT.2**
- 6 **Pnt.2**
- 7 **HGT.3**
- 8 **Pnt.3**
- 9 **Pnt.out**

Programming example:

we want to program a linearisation point so that at 1000kg, the analog output supplies 10V.




Enter **62300** (the reference value in the table) and check the analog output using a tester.



Adjust the analog output by increasing or decreasing the value.
We recommend minimal changes of at least 10 points, (**62310**, **62320**, **62330**, etc.)

How to set the value




Once the desired adjustment has been made, confirm the value with .

MENU

How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 8	← =	

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N 1
- O 2
- P 3
- Q 4




inPutS Digital inputs



Visible only in the presence of optional inputs/outputs electronic board.

Input 1 configuration



Repeat the same operation for , e .



MENU

How to enter

- 1. Off
- 2. On
- 3.
- Page 8

How to browse

- =
- =
- =
- =

How to save and exit



Page 8

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

1

P

2

Q

3

4


4

outPut Digital outputs



Visible only in the presence of optional inputs/outputs electronic board.


Operation on net weight, gross weight or dosage




For dosage / filling:

- Start the *doSAGE* mode
- Set the *unLoCH* unladen weight.

Normally open (*n.o.*) or closed (*n.c.*) operation




Output activation mode




Double threshold operation

(activation weight threshold ≠ from output deactivation weight threshold)




Operation:

YES (Double threshold)



NO (Single threshold)



NO (Single threshold)



NO (Single threshold)



Repeat the same operation for *rEL.b.2*, *rEL.b.3* and *rEL.b.4*.



MENU

How to enter

1. Off
2. On
- 3.
- (i) Page 8*

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit

*(i) Page 8***A CAL****B D.CAL****C GrAU****D SER_AL****E LAYOUT****F FILTER****G SCREEN****H batt****I ECobAT****J AutoOFF****K rENote****L An.out****M inPutS****N outPut****O rESEt****P d.iAG****Q AdUAnC****1 AdC.uU****2 d.iSPLA****3 KEYb****4 Cts****5 outPut****6 inPutS****7 An.out****8 SER.nuN****9 PrG.UEr****10 d.iU.int****11 AdC.PnT****12 bLAdC****13 PHAdC****14 SER_AL**

rESEt Factory configuration reset

**O rESEt****SurEP****d.iAG**

Function resetting the factory configurations while maintaining the calibration in the memory unchanged.

d.iAG

Diagnostics

**P-1 AdC.uU**

Converter. Check of input signal in μV . In case of more equalised channels, press or to examine all the selected channels.

P-2 d.iSPLA

Display. Integrity check of all segments and icons.

P-3 KEYb

Keyboard. Press any key to verify its correct operation, with beep and code on display.

P-4 Cts

CTS. Check of status of the control signal from the printer.

P-5 outPut

Optional digital outputs. Check the activation and deactivation of each contact.

Example: **out 1** activates output 1. Press to select the next output.

WARNING: before entering the **outPut** pitch, verify that the activation of the output does not cause dangerous conditions for people, animals or property.

P-6 inPutS

Optional digital inputs. Check the activation and deactivation of each input.

Example: **in 1-0** input not active

Example: **in 1-1** input active

Press to select the next input.

P-7 An.out

Analog output. Enter the digital value and using a tester check the response of the analog output.

P-8 SER.nuN

Serial number of the scale.

P-9 PrG.UEr

Hardware revision (e.g. **rEU5**) followed by software version (e.g. **04.00.00**).

P-10 d.iU.int

For use by the manufacturer.

P-11 AdC.PnT

For use by the manufacturer.

P-12 bLAdC

For use by the manufacturer.

P-13 PHAdC

For use by the manufacturer.

P-14 SER_AL

For use by the manufacturer.



MENU

How to enter

1. Off
2. On
- 3.
- Page 8

How to browse

- =
- =
- =
- =

How to save
and exit



Page 8

A **CAL**

B **D.CAL**

C **GrAU**

D **SEr.iAL**

E **LAYOUT**

F **FiLTER**

G **ScREEn**

H **bAtt**

I **ECobAt**

J **AutoOFF**

K **rENote**

L **An.out**

M **inPutS**

N **outPut**

O **rESET**

P **d.iAG**

Q **AdUAnC**

1 **CAL.PAr**

2 **EqUAL.P**

3 **CAL.RdU**

4 **no.iSE**

5 **NEtrol**

6 **AEyb**

7 **t.iLT**

8 **rEACT**

9 **LoCH.hb**

10 **AL.iB.iR**

11 **P.in.EEC**

12 **P.in.uSE**

13 **dFLT.E**

AdUAnC Advanced




CAL.PAr Calibration parameters




Configuration of the decimal point (0...3)

Q-1-1 **dEC.iN**




Reading division

Q-1-2 **d.iU**



Unit of measure

Q-1-3 **u.L.**





MENU

How to enter

1. Off
2. On
- 3.
- (i)* Page 8

How to browse

- =
- =
- =
- =

How to save and exit



(i) Page 8

Scale capacity. Set Max or Range 1 (Max range = 800.000)

Q-1-4 **rAnGE 1**


How to set the value



rAnGE 2

Q-1-5 **rAnGE 2**

How to set the value



rAnGE 3

Range 2

For multirange scales, set the second weighing range.

Q-1-6 **rAnGE 3**




rAnGE 1

Example of multirange configuration at 1500/3000 kg, division 0.5/1 kg.

Set:
 $dEC\ i = 0.0$
 $d\ iU = 5$
 $rAnGE\ 1 = 15000$
 $rAnGE\ 2 = 30000$

Equalisation function

Q-1-7 **EQuAL**




(i) Connection diagram on page 7.
Equalisation procedure on page 36.

Equalised analog channels

Q-1-8 **n.ChAn**

Visible only if **EQuAL**(Q-1-7)=YES



- 1 **CAL.PAr**
- 2 **EQuAL.P** 1 **dEC\ i**
- 3 **CAL.RdU** 2 **d\ iU**
- 4 **no\ YES** 3 **u.P.**
- 5 **NEtrol** 4 **rAnGE\ 1**
- 6 **AEyb** 5 **rAnGE\ 2**
- 7 **t\ LT** 6 **rAnGE\ 3**
- 8 **rEACT** 7 **EQuAL**
- 9 **LoCh.Rb** 8 **n.ChAn**
- 10 **AL\ b\ sr**
- 11 **P\ in.EEC**
- 12 **P\ in.uSE**
- 13 **dFLE.E**



MENU

How to enter

1. Off
2. On
- 3.
- (i)* Page 8

How to browse

- | | |
|-------------------|---|
| = | = |
| = | = |
| <i>(i)</i> Page 8 | |

How to save and exit

A **CAL**B **D.CAL**C **GrAU**D **SEr.iAL**E **LAYout**F **FiLTER**G **ScREEn**H **bAtt**I **ECo.bAt**J **AutoOFF**K **rENote**L **An.out**M **inPutS**N **outPut**O **rESEt**P **d.iAG**Q **AdUAnC**1 **CAL.PAr**2 **EQuAL.P**3 **CAL.Rdu**1 **E9.0**4 **no.iSE**2 **E9.1**5 **NEtrol**3 **E9.2**6 **AEYb**4 **E9.3**7 **t.iLT**5 **E9.4**8 **rEACE**9 **LoCH.fib**10 **AL.iB.iR**11 **P.in.EEC**12 **P.in.uSE**13 **dFLT.E**


EQuAL.P Equalisation



(i) **EQuAL.P** is only visible if the function **EQuAL** (Q-1-7) is activated in the menu **CAL.PAr** (Q-1).

The equalisation wizard asks to acquire the zero point with scale unloaded and to later place a weight of about 1/8 of the maximum capacity (Max) on each individual cell, in the required order. After the procedure the message **E9.oF** will appear.

Proceed with the calibration.



- Q-2-1** **E9.0** -oF- **E9.1**
- Q-2-2** **E9.1** -oF- **E9.2**
kg = 1/8 Max (kg)
- Q-2-3** **E9.2** -oF- **E9.3**
kg
- Q-2-4** **E9.3** -oF- **E9.4**
kg
- Q-2-5** **E9.4** -oF- **CAL**





MENU

How to enter

1. Off
2. On
- 3.
- (i)* Page 8

How to browse

- ↑ =
- ↓ =
- =
- ← =

How to save and exit



(i) Page 8

A **CAL**

B **O.CAL**

C **GrAU**

D **SEr.iAL**

E **LAYout**

F **FILEEr**

G **SCrEEEn**

H **bAtt**

I **ECobAtt**

J **AutoOFF**

K **rENoteE**

L **An.out**

M **inPutS**

N **outPut**

O **rESEtE**

P **d.iAG**

Q **AdUAnC**

1 **CAL.PAr**

2 **EqUAL.P**

3 **CAL.Adu**

4 **no.iSE**

1 **2Ero**

5 **NEtrol**

6 **AEYb**

7 **t.iLT**

8 **rEACT**

9 **LoCH.Rb**

10 **AL.iB.iR**

11 **P.in.EEC**

12 **P.in.uSE**

13 **dFLE.E**

CAL.Adu Complete calibration

(i) Before calibrating, configure the decimals (**DEC** - Q-1-1), the division (**d.iU** - Q-1-2) and the capacity (**rANGE** - Q-1-4,5,6).

Start of the calibration procedure:

Q-3-1 **2Ero**

Unload the plate, press and wait for the message **-oH-**.



CAL.Pnt

Now acquire the calibration points (up to 3):

I. Set the calibration points (**1...3**)

How to set the value



000.000

II. Enter the calibration weight

How to set the value



III. Load the weight and wait

-oH-

000.000

Repeat the steps from II. for the next points

CAL.oF

CAL.Pnt




MENU

How to enter	How to browse	How to save and exit
1. Off	=	
2. On	=	
3.	=	
Page 8	=	Page 8

- A CAL
- B D.CAL
- C GrAU
- D SEr.iAL
- E LAYOUT
- F FILTER
- G SCREEN
- H bATT
- I ECO.bAT
- J AutoOFF
- K rENote
- L An.out
- M inPutS
- N outPut
- O rESET
- P d.iAG
- Q AdUAnC
 - 1 CAL.PAr
 - 2 EqUAL.P
 - 3 CAL.Adu
 - 4 no.iSE
 - 5 NEtrol
 - 6 REyb
 - 7 t.iLT
 - 8 rEACT
 - 9 LoCH.Rb
 - 10 AL.iB.iR
 - 11 P.in.EEC
 - 12 P.in.uSE
 - 13 dFLTE.E


Additional filter for weighing in the presence of vibrations and for weighing live animals.




To weigh live animals, we recommend the combination with filter **StAnd** (F-1,2,3,4) or **SLow** (F-17,18,19,20). (See page 25)

NEtrol Metrological parameter


Reset percentage via key



Sensitivity of the weight stability control



Zero hold function (tracking)




MENU


How to enter	How to browse	How to save and exit
1. Off	↑ =	How to save and exit
2. On	↓ =	
3.	→ =	
Page 8	← =	Page 8

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P
- Q
- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13

Reset at power and reset percentage



Re-acquisition / change of the calibration points in memory.




Repeat the same operation for Po.int.1, Po.int.2 e Po.int.3


Q-5-6 For use by the manufacturer.

Q-5-7 For use by the manufacturer.

Type of keyboard



Inclinometer (for use by the manufacturer)



Normally open


Normally closed

MENU


How to enter	How to browse	How to save and exit
1. Off	↑ =	
2. On	↓ =	
3.	→ =	
Page 8	← =	Page 8

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P
- Q
 - 1
 - 2
 - 3
 - 4
 - 5
 - 6
 - 7
 - 8
 - 9
 - 10
 - 11
 - 12
 - 13


Reactivation of the totalisation or print function




Permanent keyboard lock (excluding key C)



Reset of fiscal memory (alibi memory, optional)




Access PIN to programming menu



Access PIN to user menus



Total reset of memory and of calibration, with reset of the factory settings.



6. COMMUNICATION STRINGS

Short string

01ST,GS, 0.0,kg<CR><LF>

where

01	Code 485 of the instrument (2 characters), only if communication mode 485 is enabled
ST	Scale status (2 characters): <u>US</u> - Weight unstable <u>ST</u> - Weight stable <u>OL</u> - Weight overload (out of range) <u>UL</u> - Weight underload (out of range) <u>TL</u> - Scale not level (inclinometer active)
,	ASCII 044 character
GS	Type of weight data (2 characters)
,	ASCII 044 character
0.0	Weight (8 characters including the decimal point)
,	ASCII 044 character
kg	Unit of measurement (2 characters)
<CR><LF>	Transmission terminator, characters ASCII 013 and ASCII 010

Extended string

01ST,1, 0.0,PT 20.8, 0,kg<CR><LF>

where

01	Code 485 of the instrument (2 characters), only if communication mode 485 is enabled
ST	Scale status (2 characters): <u>US</u> - Weight unstable <u>ST</u> - Weight stable <u>OL</u> - Weight overload (out of range) <u>UL</u> - Weight underload (out of range) <u>TL</u> - Scale not level (inclinometer active)
,	ASCII 044 character
1	ASCII 049 character
,	ASCII 044 character
0.0	Net weight (10 characters including the decimal point)
,	ASCII 044 character
PT	Indication of pre-set manual tare (2 characters)
20.8	Tare weight (10 characters including the decimal point)
,	ASCII 044 character
0	Number of pieces (10 characters)
,	ASCII 044 character
kg	Unit of measurement (2 characters)
<CR><LF>	Transmission terminator, characters ASCII 013 and ASCII 010



7. COMMUNICATION CONTROLS

Premise:

in the serial controls and in the relative responses

nn	Address 4B5 of the instrument (2 characters) (only if communication mode 4B5 is activated)
<CR>	Terminator character ASCII 13 (0D) (1 character)
<LF>	Terminator character ASCII 10 (0A) (1 character)

Reading of simple weight

Control	nnREAD<CR><LF>
Response	Short string (see page 41)

Reading of complete weight

Control	nnREXT<CR><LF>
Response	Extended string (see page 41)

Execution of a semi-automatic tare

Control	nnTARE<CR><LF>
Response	OK<CR><LF> indicates that the control was received correctly

Setting of the tare value (PT)

Control	nnTMAnnnnnn<CR><LF>
	Where t...t is the tare, with decimal points, max 8 characters.
Response	OK<CR><LF> indicates that the control was received correctly
Examples	TMAN1.56<CR><LF> set a tare of 1.56
	TMAN100<CR><LF> set a tare of 100

Deleting the tare in memory

Control	nnCLEAR<CR><LF>
Response	OK<CR><LF> indicates that the control was received correctly

Scale reset (function of the ZERO key)

Control	nnZERO<CR><LF>
Response	OK<CR><LF> indicates that the control was received correctly

SPECIFIC CONTROLS FOR ALIBI MEMORY (OPTIONAL)

Storage requests

Control	nnPID<CR><LF> request to store the weight
Response	recording successful nnPIDss,c,wwwwwwwwuu,ppttttttttuu,xxxxx-yyyyyy<CR><LF>
	no recording nnPIDss,c,wwwwwwwwuu,ppttttttttuu,NO<CR><LF>
where:	
ss	status of weight (2 characters)
TL	Error of condition of <i>t<small>o</small>u<small>e</small>r<small>l</small><small>a</small><small>r</small><small>d</small></i> (NO RECORDING)
OL	Condition of <i>o<small>u</small>l<small>e</small>r<small>l</small><small>a</small><small>r</small><small>d</small></i> (NO RECORDING)
UL	Condition of <i>u<small>u</small>n<small>d</small><small>e</small>r<small>l</small><small>a</small><small>r</small><small>d</small></i> (NO RECORDING)
ST	Weight stable
US	Weight unstable (NO RECORDING)
c	Scale number (1 character)
w...w	Gross weight (10 characters)
uu	Unit of measurement (2 characters)
pp	Type of tare: double space " " if semi-automatic, "PT" if pre-set (2 characters)
t...t	Tare value (10 characters)
xxxxx	Number of rewriting (5 characters)
yyyyyy	Progressive weighted (6 characters)
Examples	PIDST,1, 1500,0kg,PT 2,8kg,00000-000158<CR><LF> PIDUS,1, 1500,0kg,PT 2,8kg,NO<CR><LF>


Reading of a weighing in memory

Control	nnALRDxxxxx-yyyyyy<CR><LF>
	Where xxxxx is the rewriting number, yyyyyy is the progressive weighted.
Response	s , w w w w w w w w w u u , p p t t t t t t t t u <CR><LF>
where:	
s	Number of scales (always 1)
w...w	Gross weight (10 characters)
uu	Unit of measurement ("g", "kg", "t", "lb")
pp	Type of tare: double space " " if semi-automatic, "PT" if pre-set (2 characters)
t...t	Tare value (10 characters)
Examples	ALRD00000-000158<CR><LF> 1, 1500,0kg, 2,8kg<CR><LF>





8. WIRING SCHEMES

DFWLxxx, WLB, TPWNxxx, TPWLxxx, MCWNxxx.



DFWLIDxxx





9. PROGRAMMING ERRORS

MESSAGE	DESCRIPTION	SOLUTION
<i>AL.Err</i>	Board "alibi memory" (optional) not detected.	Check the presence of the board inside the indicator. If present, check it is not damaged and is installed correctly.
<i>Er.Ib.H</i>	Board "inputs/outputs" (optional) not detected.	Check the presence of the board inside the indicator. If absent, deactivate any inputs or outputs (parameter " <i>inPut5</i> " or " <i>outPut</i> ", see page 31-32). If present, check it is not damaged and is installed correctly.
<i>Er.r.b.H</i>	Board "inputs/outputs" (optional) not detected.	Check the presence of the board inside the indicator. If absent, deactivate any inputs or outputs (parameter " <i>inPut5</i> " or " <i>outPut</i> ", see page 31-32). If present, check it is not damaged and is installed correctly.
<i>E9.Err</i>	Impossible to perform equalisation.	Check the cells are connected properly. Check the signal of each cell in the diagnostic menu (menu <i>d.iRG</i> , parameter <i>AdC.uU</i> , see page 33).
<i>PrEC.</i>	Calibration error.	First calibrate the zero point, then proceed with the next points.
<i>Err.Pnt</i>	Calibration error.	Check the connection of the load cell. Check that the cell signal is stable, valid and greater than that of the previously acquired point.
<i>Er.11</i>	Calibration error.	Increase the calibration weight.
<i>Er.12</i>	Calibration error.	Check that the signal coming from the cell increases upon the increasing of the weight loaded on the scale. When acquiring the calibration points, use the increasing calibration weights.
<i>Er.37</i>	Calibration error.	Repeat the calibration, checking that the capacity and division have been correctly set.
<i>Er.39</i>	Instrument not configured.	Reset the factory configurations (menu <i>AdUAnE</i> , parameter <i>dFLtE</i> , see page 40).
<i>Er.85</i>	Instrument configured but not calibrated.	Perform calibration.
<i>C.Er.36</i>	Calibration error.	Check that the signal coming from the load cell is not negative.
<i>Err.Not</i>	Weight unstable.	Check in menu <i>d.iRG</i> , parameter <i>AdC.uU</i> (see page 33) that the signal is stable and re-try. If the connection of the cells is with 4 wires, check that the sense jumpers are inserted.



10. FAQ - FREQUENTLY ASKED QUESTIONS

Calibration

Can I change the maximum capacity without recalibrating?

Yes, you must change the parameters `RANGE 1,2,3` (Q-1-4,5,6). (See page 35)

Can I change the division without recalibrating?

Yes, you must change the parameter `d.iU` (Q-1-2). (See page 35)

Can I change the position of the decimal point without recalibrating?

Yes, you must change the parameter `dEC.iU` (Q-1-1) and the value of the calibration points via the pitch `CAL.PAn` (Q-5-6). (See page 35 and 39)

Can I calibrate the instrument in "multi-division" mode?

Yes, through advanced configuration from PC with Dinitools program.

Communication

Scale doesn't answer

- Check the good condition of the cable and that there are no failures (using a multimeter).
- Check that the PC communication port or of the device used is not compromised. If necessary, try with another device/PC
- Make sure to have connected the cable on the correct serial port.
- Check the configuration of the pitches `bRud` and `bIt`. (See page 13)
- Temporarily activate the continuous communication and retry receiving the string. If the string has been received correctly, carefully check the syntax of the control sent, the communication time-outs and the presence of the terminator.

Generic

The scale does not switch on

- Check that the input voltage level to the mother board is correct.
- Try the forced power by inserting the "ON BOOT" jumper present on the mother board. If the indicator lights up, check the correct operation of the keyboard, using the diagnostic menu `d.RG`. (See page 33)
- Possible failure of the internal rechargeable battery (if present).



11. SUMMARY OF THE PARAMETERS

CAL	Calibration.....	10
dIV	Division	10
DCAL	Reset of Pre-Tare (zero calibration).....	11
GRAV	Area of gravity of the place of use.....	11
SERIAL	Configuration of the serial ports	12
CoN.PC	Communication with PC, PLC or repeater.....	12
Node	Selection of the communication mode	12
CoNSEL	Selecting the COM port for connection with PC/PLC.....	13
bAud	Communication speed (baud rate).....	13
bIt	Configuration of the serial protocol	13
CoN.PRN	Communication with printer or repeater or PC.....	14
Node	Selection of the communication mode.....	14
bAud	Communication speed (baud rate).....	14
bIt	Configuration of the serial protocol	15
Cts	Printer control signal.....	15
PoWER.P	Printer power supply / radio-frequency module.....	15
AdUAnC	Advanced configurations.....	16
ProtoC	Communication protocol.....	16
rAd io	Connection port of radio-frequency module (for use by the manufacturer).....	16
TTL_E.iL	TTL port / Inclinometer activation (for use by the manufacturer).....	16
EEn	Closing character of each print line.....	16
LAYOUT	Print customisation.....	17
LAng	Setting of the print language (iEAL , EnGL , dEut , FrAn , ESPA , Ch inES)	18
ChAr	Setting the character	18
hEAdEr	Print header.....	19
dAtA	Selection of the weight data.....	21
HE iGht	Progressive weighed	21
E iCFET	Receipt / label progressive	21
CLoCH	Date and time.....	22
BarC39	Barcode 39.....	22
BarC.uP	Barcode top margin (mm)	22
BarC.L	Barcode left margin (mm).....	22
BarC.h	Barcode height (mm).....	22
BarC.dt	Selection of the weight data.....	23
CoP.iES	Multi-copy prints.....	23
Endt.iC	Paper outlet for end of label / receipt.....	23
bL.inE	White pre-heating line of the print head (for thermal printer only).....	23
LAbel	Label configuration.....	24
LB.SAVE	Saving of labels in the printer memory.....	24
TESt	Saving of labels in the printer memory and test print of all formats	24
FiLTER	Weighing filters.....	25
ScREEn	Adjusting the display.....	26
BAcL.iT	Backlighting	26
br.iGht	Brightness.....	26
LoCk	Display lock (for use by the manufacturer)	26
CoLour	Backlighting colour (in versions with colour display)	26

bAtt	Power supply via battery	27
ECobAt	Energy saving for battery operation	27
AutoFF	Auto off	28
rEmote	Remote control	28
An.out	Analog output	29
inPutS	Digital inputs	31
outPut	Digital outputs	32
rESEt	Factory configuration reset	33
dIAG	Diagnostics	33
AdC.uU	Converter	33
dISPLA	Display	33
KEYb	Keyboard	33
AdUAnC	Advanced	34
CAL.PAr	Calibration parameters	34
dEC.in	Configuration of the decimal point	34
d.iU	Reading division	34
u.U.	Unit of measure	34
rAnGE.1	Scale capacity (maximum capacity / first weighing range)	35
rAnGE.2	For multirange scales (second weighing range)	35
rAnGE.3	For multirange scales (third weighing range)	35
EqUAL	Equalisation function	35
n.ChAn	Equalised analog channels	35
EquAL.P	Equalisation	36
CAL.Rdu	Complete calibration	37
no.iSE	Additional filter for weighing in the presence of vibrations and for weighing live animals	38
MEtroL	Metrological parameters	38
OPErC	Reset percentage via key 	38
d.iUSTb	Sensitivity of the weight stability control	38
0.Erh	Zero hold function (tracking)	38
on2Ero	Reset at power and reset percentage	39
CAL.Rdu	Re-acquisition / change of the calibration points in memory	39
CAL.RAn	For use by the manufacturer	39
dSALE	For use by the manufacturer	39
KEYb	Type of keyboard	39
E.iLT	Inclinometer (for use by the manufacturer)	39
rEACT	Reactivation of the totalisation or print function	40
LoCK.b	Permanent keyboard lock (excluding key )	40
AL.iB.uR	Reset of fiscal memory (alibi memory, optional)	40
P.inEEC	Access PIN to programming menu	40
P.inUE	Access PIN to user menus	40
dFLtE	Total reset of the memory and of calibration	40



NOTES

**HEAD OFFICE**

Via Della Fisica, 20
41042 Spezzano di Fiorano, Modena - Italy
Tel. +39 0536 843418 - Fax +39 0536 843521

SERVICE ASSISTANCE

Via Dell'Elettronica, 15
41042 Spezzano di Fiorano, Modena - Italy
Tel. +39 0536 921784 - Fax +39 0536 926654

www.diniargeo.com

Authorized service center stamp

