





Defender™ 3000 Indicators Instruction Manual



i-DT33P



i-DT33XW

Table of Contents

| | | |
|-----------|--|-----------|
| 1. | INTRODUCTION | 3 |
| 1.1. | SAFETY PRECAUTIONS | 3 |
| 1.2. | INTENDED USE | 3 |
| 1.3. | OVERVIEW OF PARTS AND CONTROLS | 4 |
| 1.4. | MAINBOARD | 5 |
| 1.5. | CONTROL FUNCTIONS | 6 |
| 2. | INSTALLATION | 8 |
| 2.1 | UNPACKING | 8 |
| 2.2 | EXTERNAL CONNECTIONS..... | 8 |
| 2.2.1 | Battery Power Supply | 8 |
| 2.2.2 | AC Power Supply | 8 |
| 2.3 | INTERNAL CONNECTIONS | 9 |
| 2.3.1 | Open the Housing..... | 9 |
| 2.3.2 | EasyConnect™ Indicator | 13 |
| 2.3.3 | Non-EasyConnect™ Indicator | 13 |
| 2.3.4 | i-DT33P RS232 Connection | 17 |
| 2.3.5 | i-DT33XW RS232 Connection | 17 |
| 2.4 | MOUNTING BRACKET..... | 18 |
| 3. | OPERATION | 19 |
| 3.1 | TURNING THE SCALE ON/OFF..... | 19 |
| 3.2 | WEIGHING MODE | 19 |
| 3.2.1 | Enter the Mode and Start Weighing | 19 |
| 3.2.2 | Application Settings | 19 |
| 3.3 | COUNTING MODE | 20 |
| 3.3.1 | Enter the Mode | 20 |
| 3.3.2 | Start Counting | 20 |
| 3.3.3 | Application Settings | 20 |
| 3.4 | CHECK | 21 |
| 3.4.1 | Set Check Limits..... | 21 |
| 3.4.2 | Positive Check..... | 21 |
| 3.4.3 | Negative Check..... | 21 |
| 3.4.4 | Zero Check..... | 21 |
| 3.4.5 | Application Settings | 21 |
| 3.5 | TOTALIZATION | 23 |
| 3.5.1 | Application Settings | 23 |
| 3.5.2 | Enter the Mode | 23 |
| 3.5.3 | Totalization Method..... | 23 |
| 3.5.4 | View Totalization Result..... | 23 |
| 3.5.5 | Totalization Rules..... | 24 |
| 3.5.6 | Print Totalization Result and Format | 24 |
| 3.5.7 | Application Settings | 25 |
| 4. | MENU SETTINGS | 26 |
| 4.1 | MENU NAVIGATION | 26 |
| 4.1.1 | User Menu (in segments) | 26 |
| 4.1.2 | Button Navigation | 27 |
| 4.2 | CALIBRATION MENU | 28 |
| 4.2.1 | Initial Calibration..... | 28 |
| 4.2.2 | Zero Calibration [ZEF]..... | 28 |
| 4.2.3 | Span Calibration [SPAN]..... | 28 |
| 4.2.4 | Linearity Calibration [L #]..... | 29 |
| 4.2.5 | GEO Code Adjustment [GEO]..... | 29 |
| 4.2.6 | Calibration Test [L-E5E] | 30 |
| 4.2.7 | End Cal [End] | 30 |
| 4.3 | SETUP MENU | 31 |
| 4.4 | READOUT MENU | 33 |
| 4.5 | UNIT MENU..... | 35 |
| 4.6 | COMMUNICATION | 35 |

| | | |
|-----------|---------------------------------|-----------|
| 4.6.1 | RS232 Menu | 35 |
| 4.6.2 | Print Menu | 37 |
| 4.6.3 | USB Configuration | 39 |
| 4.6.4 | Ethernet Configuration..... | 39 |
| 4.7 | LOCK BUTTON CONFIGURATION | 40 |
| 5. | LEGAL FOR TRADE..... | 41 |
| 5.1 | SETTINGS..... | 41 |
| 5.2 | VERIFICATION | 41 |
| 5.3 | SEALING | 42 |
| 6. | MAINTENANCE | 44 |
| 6.1 | CLEANING..... | 44 |
| 6.2 | TROUBLESHOOTING | 45 |
| 6.3 | SERVICE INFORMATION | 45 |
| 7. | TECHNICAL DATA..... | 46 |
| 7.1 | SPECIFICATIONS | 46 |
| 7.2 | TABLE OF GEO CODE VALUES | 48 |
| 8. | COMPLIANCE | 49 |
| 9. | APPENDICES | 51 |
| 9.1 | APPENDIX A..... | 51 |
| 9.2 | APPENDIX B..... | 53 |
| 9.3 | APPENDIX C..... | 54 |
| 9.4 | APPENDIX D..... | 55 |
| | LIMITED WARRANTY | 56 |

1. INTRODUCTION

This manual contains installation, operation and maintenance instructions for i-DT33P and i-DT33XW indicators. Please read it completely before installation and operation.

1.1. Safety Precautions

Definition of Signal Warnings and Symbols

Safety notes are marked with signal words and warning symbols. These show safety issues and warnings. Ignoring the safety notes may lead to personal injury, damage to the instrument, malfunctions and false results.

| | |
|-----------|--|
| WARNING | For a hazardous situation with medium risk, possibly resulting in severe injuries or death if not avoided. |
| CAUTION | For a hazardous situation with low risk, resulting in damage to the device or the property or in loss of data, or minor or medium injuries if not avoided. |
| ATTENTION | For important information about the product. May lead to equipment damage if not avoided. |
| NOTE | For useful information about the product. |

Warning Symbols



General hazard



Explosion hazard



Electrical shock hazard

Safety Precautions



CAUTION: Read all safety warnings before installing, making connections, or servicing this equipment. Failure to comply with these warnings could result in personal injury and/or property damage. Retain all instructions for future reference.

- Before connecting power, verify that the equipment's input voltage range and plug type are compatible with the local AC mains power supply.
- Do not position the equipment such that it is difficult to reach the power connection.
- Only connect the power cord to a compatible grounded electrical outlet.
- Only use a power cord with a rating that exceeds the specifications on the equipment label. (Only for i-DT33P)
- Make sure that the power cord does not pose a potential obstacle or tripping hazard.
- Operate the equipment only under ambient conditions specified in these instructions.
- The equipment is for indoor use only.
- Do not operate the equipment in hazardous or unstable environments.
- Do not allow liquids to enter the equipment.
- Use only approved accessories and peripherals.
- Disconnect the equipment from the power supply when cleaning.
- Service should only be performed by authorized personnel.



WARNING: Never work in an environment subject to explosion hazards! The housing of the instrument is not gas tight. (Explosion hazard due to spark formation, corrosion caused by the ingress of gases).



WARNING: Electrical shock hazards exist within the housing. The housing should only be opened by authorized and qualified personnel. Remove all power connections to the unit before opening.

1.2. Intended Use

This instrument is intended for use in laboratories, pharmacies, schools, businesses and light industry. It must only be used for measuring the parameters described in these operating instructions. Any other type of use and operation beyond the limits of technical specifications, without written consent from OHAUS, is considered as not intended. This instrument complies with current industry standards and the recognized safety regulations; however, it can constitute a hazard in use. If the instrument is not used according to these operating instructions, the intended protection provided by the instrument may be impaired.

1.3. Overview of Parts and Controls




Figure 1-1 i-DT33P Indicator

| Item | Description | Item | Description |
|------|---------------------|------|----------------------|
| 1 | Front Housing | 6 | Battery Cover |
| 2 | Control Panel | 7 | Mounting Bracket |
| 3 | Rear Housing | 8 | Power Cord Connector |
| 4 | Screws (5) | 9 | RS232 Connector |
| 5 | Adjusting Knobs (2) | 10 | Load Cell Connector |




Figure 1-2 i-DT33XW Indicator

| Item | Description |
|------|------------------------------|
| 1 | Front Housing |
| 2 | Control Panel |
| 3 | Load Cell Connector |
| 4 | Strain Relief for Option |
| 5 | Strain Relief for Power Cord |
| 6 | Rear Housing |
| 7 | Adjusting Knobs (2) |
| 8 | Hex Head Bolts (6) |

Note:

- There are two types of load cell connector, one supports EasyConnect™ and one does not. Therefore the load cell connector varies for different models.
- For some i-DT33XW models, the position of load cell connector, strain relief for option and power cord may change. Please refer to the actual product.

1.4. Mainboard




Figure 1-3 i-DT33P Mainboard

| Item | Description | Item | Description |
|------|--|------|--|
| 1 | DC input (J1) | 7 | Display board connector (J9) |
| 2 | Dry cell input (J2) | 8 | Load cell terminal block (J11) (for models not supporting EasyConnect™) |
| 3 | Ethernet kit / USB device kit connector (J5) | 9 | Load cell connector (J12) (for models supporting EasyConnect™) |
| 4 | Backlight connector (J10) | 10 | Lead-acid battery charge board kit connector (J8) |
| 5 | RS232 connector (J13) | 11 | Security switch connector (S1) |
| 6 | Keyboard connector (J4) | | |




Figure 1-4 i-DT33XW Mainboard

| Item | Description | Item | Description |
|------|--|------|--|
| 1 | DC input (J1) | 6 | Keyboard connector (J13) |
| 2 | Lead-acid battery input (J2) | 7 | Display board connector (J9) |
| 3 | Ethernet kit / USB device kit connector (J5) | 8 | Load cell terminal block (J11) (for models not supporting EasyConnect™) |
| 4 | RS232 connector (J8) | 9 | Load cell connector (J12) (for models supporting EasyConnect™) |
| 5 | Backlight connector (J10) | 10 | Security switch connector (S1) |

Note: Mainboard may vary slightly for different regions.

1.5. Control Functions




Figure 1-5 i-DT33P Control Panel




Figure 1-6 i-DT33XW Control Panel

| Button | On/Zero Off Yes | Print Units No | Function Mode Back | Tare Menu Exit |
|------------------------------------|---|--|--|--|
| Primary Function (Short Press) | On/Zero If the terminal is off, press to power on; If the terminal is on, press to set the zero point. | Print Sends the current value to the RS232 port if the Print Setup → Assignment → Demand menu is enabled. | Function Initiates an application mode. | Tare Performs a tare operation. |
| Secondary Function (Long Press) | Off If the terminal is on, press to power off. | Units Changes the weighing unit. | Mode Changes the application mode. | Menu Enters the user menu. Shows a tare value in application modes. |
| Menu Function (Short Press) | Yes Accepts the current setting on the display or selects a sub-menu or menu item. | No Advances to the next menu or menu item. Rejects the current setting on the display and advances to the next available one. | Back Moves back to the previous menu item. | Exit Exits the user menu. Aborts a calibration in progress. Exits when displaying totalization result or under and over value in check mode. |

Notes:

- Short Press: press less than 1 second.
- Long Press: press and hold for more than 3 seconds.




Figure 1-7 Display

| Item | Description | Item | Description |
|------|-----------------------|------|-----------------------------------|
| 1 | NET symbol | 7 | Pound, Ounce, Pound:Ounce symbols |
| 2 | Center of Zero symbol | 8 | Kilogram, Gram symbols |
| 3 | Stable weight symbol | 9 | Pieces symbol |
| 4 | Negative symbol | 10 | Percent symbol, Tonne symbol |
| 5 | Preset tare symbol | 11 | Battery symbol |
| 6 | Totalization symbol | | |

2. INSTALLATION

2.1 Unpacking

Unpack the following items:

- i-DT33P or i-DT33XW indicator
- Rechargeable battery (i-DT33XW)
- Rechargeable battery (supplied in some regions for i-DT33P)
- Mounting bracket
- Knobs (2)
- Quick installation guide
- Instruction manual
- Two jumper wires supplied for connecting a 4-wire load cell cable.
- One ferrite core (supplied with some models for connecting load cell connector)

2.2 External Connections

2.2.1 Battery Power Supply

i-DT33P

Use 6 C size dry batteries (not included).

In some regions, the i-DT33P model comes with one lead-acid battery installed by factory.

Note: You can contact an authorized OHAUS dealer to buy the lead-acid battery as an option.

i-DT33XW

This model comes with one lead-acid battery installed by factory default.

Note: The lead-acid battery will charge automatically while connecting to the power supply. When charging, the battery level indicator increases or decreases in one grid, two grids, three grids and four grids. The battery level indicator will disappear when the battery is fully charged.

While operating on battery, the battery symbol indicates the battery status:



Battery 5%~25% remaining



Battery 25%~50% remaining



Battery 50%~75% remaining



Battery 75%~100% remaining



Attention: Before using the indicator for the first time, the internal rechargeable battery should be fully charged for up to 12 hours. The indicator can be operated during the charging process. The battery is protected against overcharging and the indicator can remain connected to the AC power line.



CAUTION: BATTERY IS TO BE REPLACED ONLY BY AN AUTHORIZED OHAUS SERVICE DEALER. RISK OF EXPLOSION CAN OCCUR IF THE RECHARGEABLE BATTERY IS REPLACED WITH THE WRONG TYPE OR IF IT IS NOT PROPERLY CONNECTED. DISPOSE OF THE RECHARGEABLE BATTERY ACCORDING TO LOCAL LAWS AND REGULATIONS.



Dispose of the lead acid battery according to local laws and regulations.

2.2.2 AC Power Supply

Connect the AC plug to an electrical outlet to power on the indicator. Connect the other end to the indicator if not connected.

2.3 Internal Connections

Some internal connections require to open the housing first. Therefore, please check the **Open the Housing** section below before making connections.




CAUTION: ELECTRICAL SHOCK HAZARD. REMOVE ALL POWER CONNECTIONS TO THE INDICATOR BEFORE SERVICING OR MAKING INTERNAL CONNECTIONS. THE HOUSING SHOULD ONLY BE OPENED BY AUTHORIZED AND QUALIFIED PERSONNEL, SUCH AS AN ELECTRICAL TECHNICIAN.


2.3.1 Open the Housing

2.3.1.1 i-DT33P


1. Turn the two knobs (circled) on each side of the indicator to disassemble the bracket.



2. Remove the five screws (circled) from the rear housing.



3. Open the rear housing.



4. Close the housing and retighten the screws after finishing internal connections


Note: The screws should be tightened to 1 N•m (8-9 in-lb) torque.

2.3.1.2 i-DT33P (with Lead-acid Battery)


i-DT33P comes with a lead-acid battery installed in some regions. Please follow the instruction below for opening the housing and take out the battery.

Note: If your indicator does not contain the lead-acid battery but you want to purchase it as an accessory, you can contact an authorized OHAUS dealer to obtain it.


1. Remove the battery cover in the direction of the arrow.




2. Take out the lead-acid battery (circled).




3. Slightly push the end of the charging cover (circled) in the direction of the arrow and take it out.




4. Remove the two screws on the charging board (circled) and take it out.



5. Remove the five screws (circled) from the rear housing.



6. Open the rear housing.




7. Close the rear housing, retighten the screws and re-install the lead-acid battery after finishing internal connections


Note: The screws should be tightened to 1 N•m (8-9 in-lb) torque.

2.3.1.3 i-DT33XW


1. Turn the two knobs (circled) on each side of the indicator to disassemble the bracket.



2. Remove the six hex head bolts from the rear housing of the indicator.



3. Open the rear housing.



4. Close the housing and re-install the bolts after finishing internal connections

Note: The bolts should be tightened to 2.5 N•m (20-25 in-lb) torque to ensure a watertight seal.

2.3.2 EasyConnect™ Indicator

To connect an OHAUS EasyConnect™ scale base to an i-DT33P or an i-DT33XW EasyConnect™ indicator, plug the base's connector into the external load cell connector located at the back (i-DT33P) or bottom (i-DT33XW) of the indicator. Then rotate the base connector's locking ring in the direction of the arrows demonstrated below.




Figure 2-1 i-DT33P




Figure 2-2 i-DT33XW

Note: For connecting bases which do not support EasyConnect™ to an EasyConnect™ indicator, contact an authorized OHAUS dealer to obtain a load cell cable gland kit (P/N 30379716) as an accessory.


2.3.3 Non-EasyConnect™ Indicator

To connect a non-EasyConnect™ scale base to an i-DT33P or an i-DT33XW non-EasyConnect™ indicator, follow the instruction in **Open the Housing** section to open the housing first before proceeding.


Note: For connecting EasyConnect™ bases to a non-EasyConnect™ indicator, contact an authorized OHAUS dealer to obtain a load cell cable gland kit (P/N 30427858) as an accessory.

2.3.3.1 i-DT33P

1. After opening the housing, release the load cell connector (circled) on the rear of the indicator and then pass the load cell cable through it.




2. Connect all the cables on the load cell cable to the load cell terminal block on the mainboard (circled). Please refer to the **Load Cell Terminal Block** section for details of the connections.




2.3.3.2 i-DT33XW


1. After opening the housing, unplug the battery connectors (circled) and take out the battery.




2. Unscrew the two screws on the sealing cover (circled), take out the cover, and then take out the first layer of the built-in housing.



3. Release the load cell connector (circled) on the bottom of the indicator and then pass the load cell cable through it.



4. Connect all the cables on the load cell cable to the load cell terminal block on the mainboard (circled). Please refer to the **Load Cell Terminal Block** section for details of the connections.



2.3.3.3 Load Cell Terminal Block

Proceed with the previous section, to connect the load cell terminal block, first locate it on the mainboard following the instruction in the previous two sections for the two models.

After finding the load cell terminal block, check table 2-1 for the definition of each terminal screw connection and make connections based on it. Please note that when using four-wire load cells, jumpers (the two short wires supplied) must be placed between the +Excitation (+EXE) and +Sense (+SEN) terminals and between the -Excitation (-EXE) and -Sense (-SEN) terminals.

The i-DT33P and i-DT33XW indicators are designed to support both 2mV/V and 3mV/V load cells from the same circuitry. A load cell output rating selection jumper is not required.




Figure 2-3 load Cell Terminal Block

Table 2-1 Jumper Connections

| Number | Connection |
|--------|------------|
| 1 | +EXE |
| 2 | +SEN |
| 3 | +SIG |
| 4 | GND |
| 5 | -SIG |
| 6 | -SEN |
| 7 | -EXE |

2.3.3.4 Installing the Ferrite Core

In order to meet certain electrical noise emission limits and to protect i-DT33P and i-DT33XW from external influences, it is necessary to install a ferrite core on the load cell cable connected to the indicator. The ferrite core is supplied.

To install it, simply route the cable through the center of the core. Either the complete cable or the individual wires can be wrapped through it.



Figure 2-4 Ferrite Core

2.3.4 i-DT33P RS232 Connection

Connect the optional RS232 cable to the RS232 connector on the rear housing of the i-DT33P indicator. Please refer to table 2-2 for the definition of each pin if needed.




Table 2-2 RS232 Pins

| Pin | Connection |
|-----|------------|
| 1 | N/C |
| 2 | TXD |
| 3 | RXD |
| 4 | N/C |
| 5 | GND |
| 6 | N/C |
| 7 | N/C |
| 8 | N/C |
| 9 | N/C |


Figure 2-5 i-DT33P RS232 Connector

2.3.5 i-DT33XW RS232 Connection

For i-DT33XW model, to make the RS232 connection:

1. Open the rear housing. Please refer to **Open the Housing** section for how to open the rear housing.
2. Take out the battery. Please refer to the **i-DT33XW** sub-section of **Non-EasyConnect™ Indicator** section for how to take out the battery.
3. Release the strain relief for option connector on the bottom of the indicator and remove the plug on it.
4. Pass the optional RS232 cable through the connector and attach it to the RS232 terminal block on the mainboard.
5. Attach the watertight seal to the cable and push it into the strain relief for option connector. Tighten the strain relief for option connector with the watertight seal in it to finish installation.

Note: Please check the graphic below for the parts mentioned above.



2.4 Mounting Bracket

Attach the bracket to a wall or table using fasteners (not supplied) that are appropriate for the type of mounting surface. The bracket will accommodate up to 6 mm (1/4") diameter screws. Locate the mounting holes as shown in Figure 2-7 and 2-8.




Figure 2-7 i-DT33P Mounting Bracket Dimensions




Figure 2-8 i-DT33XW Mounting Bracket Dimensions

3. OPERATION

3.1 Turning the Scale On/Off

To turn the scale on, short press the **On/Zero Off** button. The scale performs a display test, momentarily displays the software version, the GEO value and then enters the last active weighing mode.

Note: If the hardware lock switch is enabled, **LFE ON** will also be displayed briefly.

To turn the scale off, press and hold the **On/Zero Off** button until **OFF** is displayed.

3.2 Weighing Mode

Use this application to determine the weight of items in the selected unit of measure. This mode is the default factory setting.

3.2.1 Enter the Mode and Start Weighing

To enter the weighing mode:

1. Press and hold the **Mode** button until **LWE IGH** is displayed.
2. If needed, place an empty container on the pan and press the **Tare** button to tare.

Note: To check the tare weight:

- a) Long press the **Tare** button until **E.LWE** is displayed.
 - b) Release the **Tare** button and the tare weight will be displayed.
3. Add item to the pan or the container. The display shows the weight of the item.

3.2.2 Application Settings

The application can be customized for user preferences. To enter application settings:

1. Long press the **Menu** button until you see **APP.M.U.**. Release the button and wait for the display to show **C.R.L.**
2. Short press the **No** button several times until you see **APP.d.E**. Press the **Yes** button to enter the application mode settings.
3. Short press the **No** button several times to navigate until you see the selection you want.
4. Press the **Yes** button to select.
5. Repeat step 3 and 4 several times until you finish all settings.
6. Press the **Exit** button to exit.

The Weighing configurations are defined below (defaults in Bold).

| Item | Available Settings | Comments |
|-----------------------------|--------------------|-------------------------------|
| Weighing (LWE IGH) | On , Off | To enable or disable Weighing |

Note: You cannot disable Weighing if you are in the mode currently.

3.3 Counting Mode

Use this application to count the number of pieces on the pan based on an Average Piece Weight (APW).

3.3.1 Enter the Mode

1. Press and hold the **Mode** button until **COUNT** is displayed.
2. When the **Mode** button is released, the display shows **CLr.PWJ**.
 - If you need to clear the stored Average Piece Weight (APW) of the last time, press the **Yes** button, and then continue to the next step.
 - If you need to recall the stored APW of the last time and continue to use it, press the **No** button to start counting.

Note: If the display shows **CLr.PAN**, remove the weight on the pan or press the **Tare** button to tare.
3. The display shows the sample size **Pwt. 10**. To change it, short press the **No** button several times until you see the value you want.

Note:

 - Available sample size selections are 5, 10, 20, 50 and 100 (The default is 10).
 - When Legal for Trade is turned on, sample size selection 5 will not be available.
4. Place the specified quantity of pieces on the pan and press the **Yes** button to capture the current stable weight.

Note:

- Make sure all pieces in the sample are the same. Different pieces and weights will result in an inaccurate piece count.
- During the capture process, the display shows - - - - -.
- If the APW is between 0.1d and 1d, the display will show **LO.rEF** for 1.5 seconds. After that the scale will start counting.
- If the APW is less than 0.1d, the display will show **rEF.Err** for 1.5 seconds. After that it will go back to step 3, showing the sample size. Please replace a heavier batch of samples and press the **Yes** button to re-establish an APW value or change to a scale with readability suitable for your samples.

3.3.2 Start Counting

1. Place parts on the pan and read the number. The number of pieces and the Pcs icon are displayed.
2. Short press the **Function** button to temporarily display the APW. **APWJ** is displayed for 1 second, and then the APW value is displayed for 1 second with the weighing unit.

3.3.3 Application Settings

The application can be customized for user preferences. Please refer to **Application Settings** section in **Weighing Mode** for details about how to enter application settings.

The Counting Configurations are defined below (defaults in Bold).

| Item | Available Settings | Comments |
|---------------|--------------------|--------------------|
| Count (COUNT) | On, Off | To enable Counting |

Note: You cannot disable Counting if you are in the mode currently.

3.4 Check

Use this application to compare the weight of items to a target weight range.

The display color will change according to the comparing result:

- Red indicates over the target weight range
- Green indicates within the target weight range.
- Yellow indicates under the target weight range.

3.4.1 Set Check Limits

1. Press and hold the **Mode** button until **CHECK** is displayed.
2. When the **Mode** button is released, the display shows **CLr.CHr**.
 - If you want to use the stored under and over value of the last time, press the **No** button, and the scale enters check mode directly.
 - If you want to set new over and under values, press the **Yes** button and continue to the next step.
3. The display shows **Under**. Press the **Yes** button to edit the under value.
4. **000000** is flashing on the display with the unit you set.
5. To set a new under value:
 - a) Short press the **No** button several times until the desired number appears.

Note:

 - Press the **Back** button can decrease the digit.
 - If you need to set a negative value, press the **Back** button when the first digit is zero or press the **No** button when the first digit is nine.
 - b) Short press the **Yes** button to accept the number and move to the next digit.
 - c) Repeat the process until all the digits are correct.
 - d) Press the **Yes** button to accept the value. Then the display will show **Over**.

Note: Please refer to the **Button Navigation** section for details of setting digits.
6. Repeat step 3 to 5 to set the over value.
7. If the values you set are invalid, the display will show **--n0--** and go back to reset the Under and Over value.
8. If the values you set are valid, the scale will enter check mode.

Note: Short press the **Function** button can display the over and under value.

3.4.2 Positive Check

Positive check is used to determine when the material added to the scale is within the target weight range. In this case the under and over values must be positive values. (The over value must be greater than the under value.)

To start, add material to the scale pan until the display turns green.

3.4.3 Negative Check

Negative check is used to determine when the material removed from the scale is within the target weight range. In this case the under and over values are both negative values. The under value must be greater than the over value. (For example: the under value is -10; the over value is -15).

To start, place a package or bin of material on the scale and press the **Tare** button.

Remove a portion of the package or material until the display turns green.

To continue weighing multiple portions off the scale's pan, tare the scale between each portion.

3.4.4 Zero Check

Zero check is used when comparing subsequent samples to an initial reference sample. In this case, the under value must be zero or a negative value and the over value must be zero or a positive one.

Place the reference sample on the scale and press the **Tare** button.

Remove material from the scale pan until the display turns green.

3.4.5 Application Settings

The application can be customized for user preferences. Please refer to **Application Settings** section in Weighing Mode for details about how to enter application settings.

The Check configurations are defined below (defaults in Bold).

| Item | Available Settings | Comments |
|------------------------|--------------------|----------------------------|
| Check (CHECK) | On , Off | To enable or disable Check |

Note: You cannot disable Check if you are in the mode currently.

3.5 Totalization

Use this application to manually or automatically accumulate the multiple weights. Statistical data (the number of samples, the total weight, the average weight, the minimum weight, the maximum weight and the difference in weight) is stored in memory for review and printing.

3.5.1 Application Settings

There are three totalization options:

- Off (**OFF**): disable the totalization function.
- Manual (**MANU**): press the **Function** button to perform totalization manually.
- Auto (**AUTO**): the scale will perform totalization automatically.
- Note:** The default is manual.

To set the totalization option:

1. Long press the **Menu** button until you see **ME.N.U.** Release the button and wait for the display to show **C.A.L.**
2. Short press the **No** button several times to navigate until you see **NO.D.E**, press the **Yes** button.
3. Short press the **No** button several times to navigate until you see **LEGAL**. Press the **Yes** button.
4. Short press the **No** button several times to navigate between different totalization options. The three options have been introduced above. Press the **Yes** button to confirm your selection.
5. Press the **Exit** button to exit.

3.5.2 Enter the Mode

1. Press and hold the **Mode** button until **LEGAL** is displayed.
2. When the **Mode** button is released, the display shows **CLR.ACC**.
 - If you need to clear the stored totalization result of the last time, press the **Yes** button, and then start totalization.
 - If you need to recall the stored totalization result of the last time, press the **No** button to continue the totalization of the last time.

Note: If there is weight on the pan, the display will show **CLR.PAN** until the weight is removed or you press the **Tare** button to tare.

3.5.3 Totalization Method

Manual

Place an item on the pan and press the **Function** button to add the weight to totalization.

Auto

Place an item on the pan. The displayed value is totalized automatically.

The flash of the Σ icon indicates the scale has totalized the weight successfully. It will keep flashing until the weight is removed and the pan is stable.

Notes:

- The item must be removed from the pan before the next item can be totalized.
- Only stable weights are stored.
- When Legal for Trade is turned ON, for NTEP models, gross and net weight cannot be added to the same total. If the first weight is recorded in gross, the future ones should be recorded in the same way. It is the same for the net weight.

3.5.4 View Totalization Result

When there is no weight on the pan, press the **Function** button to view the result.

The result includes the number of samples, the total weight, the average weight, the minimum weight, the maximum weight and the difference in weight (the maximum weight minus the minimum weight). The values are displayed for 1 second each.

3.5.5 Totalization Rules

The totalization operation will fail when:

1. The current weight is unstable.
2. The load's net weight is smaller than 5d.
3. The overall totalized number is larger than 999999. (The unit is according to what you set for the scale.)
4. The total number of totalization exceeds 9999 times.

3.5.6 Print Totalization Result and Format

● During totalization, to print the current weight:

1. Enable the Table on (**TABLE**) option in the menu.
To do this:
 - a) Long press the **Menu** button until you see **000.000**. Release the button and wait for the display to show **0.000**.
 - b) Short press the **No** button several times to navigate until you see **000.000**. Press the **Yes** button.
 - c) Short press the **No** button several times to navigate until you see **TABLE**. Press the **Yes** button.
 - d) Short press the **No** button until you see **00** flashing on the screen. Press the **Yes** button to enable.
 - e) Press the **Exit** button to exit.
2. After the Table on option is enabled:
 - In automatic totalization mode, the scale will automatically print the current weight when it is totalized successfully.
 - In manual totalization mode, press the **Function** button to totalize the current weight and print it accordingly.

The print output for current weight will appear as the example below:

Example:

| | |
|-------|----------|
| 1. | 1000 g G |
| 2. | 2000 g G |
| 3. | 3000 g G |
| 4. | 1999 g G |
| 5. | 1000 g G |
| ----- | |

● When totalization is finished, to print the totalization result:

1. Press the **Function** button with no weight on the pan to show the totalization result.
2. Press the **Print** button to print the result while the totalization result is displayed on the screen.

Note: if you do not press the **Function** button to display the totalization result, the scale will print the print template you set.

When totalization is finished, the print output for Totalization result will appear as the example below:

Example:

| | |
|--------|--------|
| ----- | |
| n: | 5 |
| Total: | 8999 g |
| Avg: | 1800 g |
| Min: | 1000 g |
| Max: | 3000 g |
| Diff: | 2000 g |

Note: The scale supports 32 characters and the left and right content will be aligned.

3.5.7 Application Settings

The application can be customized for user preferences. Please refer to **Application Settings** section in **Weighing Mode** for details about how to enter application settings.

The Totalization Configurations are defined below (defaults in Bold).

| Item | Available Settings | Comments |
|-------------------------------|--------------------------|---|
| Totalization (TOTAL) | Off, Auto, Manual | To select Totalization method or disable it |

Note: you cannot disable Totalization if you are in the mode currently.

The Table Configurations are defined below (defaults in Bold).

| Item | Available Settings | Comments |
|------------------------|--------------------|--|
| Table (TABLE) | On, Off | To enable or disable Table for printing current weight during Totalization |

4. MENU SETTINGS

The User Menu allows the customizing of scale settings.

Note: Sub-menu for options (USB, Ethernet and Print2 in the table below) will be active only when the specific board is installed. See their separate option instruction manuals for additional setting information.

4.1 Menu Navigation

4.1.1 User Menu (in segments)

| CAL | SEtUP | rEAd | MODdE | U.n. It | A.S.2.3.2 | P.r. I.N.t | U.S.b | E.t.H.N.E.t | P.r. I.N.t2 | L.o.c.t | End |
|---------|---------|----------|---------|---------|-----------|------------|----------|-------------|-------------|----------|-----|
| ZEro | rESEt | rESEt | rESEt | rESEt | rESEt | rESEt | rESEt | rESEt | rESEt | rESEt | |
| SPAN | C.UN It | StAbLE | WJE IGH | kg | bAUD | ASS IGH | bAUD | IP.Addr | ASS IGH | L.ALL | |
| L INE | rANGE | ZEro | COUNt | g | PAR ItY | StAbLE | PAR ItY | u.E.r. | StAbLE | L.OFF | |
| GEO | CAP1 | F ILtEr | CHECt | lb | StOP | MODdE | StOP | END | MODdE | L.ZEro | |
| C.tESEt | GrAd1 | A2t | tOtAL | oz | H.SHARtE | t INtE | H.SHARtE | | t INtE | L.Pr INt | |
| End | CAP2 | b.L IGHt | tAbLE | lb:oz | ALt.P | L INtEo | ALt.P | | L INtEo | L.UN It | |
| | GrAd2 | b.COLOr | End | t | ALt.t | C.SUPP | ALt.t | | C.SUPP | L.MOdE | |
| | P.ZEro | SCrEEN | | End | ALt.2 | tEPPP | ALt.2 | | tEPPP | L.MENU | |
| | P.UN It | A.OFF | | | End | End | End | | END | L.tArE | |
| | A.tArE | P.SArEr | | | | | | | | End | |
| | End | CEC | | | | | | | | | |
| | | End | | | | | | | | | |

Notes:

Some modes/units may not be available in all models.

When LEGAL FOR TRADE is turned **ON** (the security switch S1 is in the locked position), the menu settings will be affected as below:

- Calibration function is disabled.
- Zero Range setting is locked at 2%.
- Stable Range setting is locked at 1d.
- Auto-Zero Tracking setting is locked at 0.5d.
- Filter and Units are locked at their current settings.
- Stable Only is locked at On.
- Lb:oz unit is locked at Off.
- Power saving mode is disabled.


Note: Please refer to **Legal for Trade** chapter for the position of the security switch S1.

4.1.2 Button Navigation

- The **Yes** button: allows entry into the displayed menu.
Accepts the displayed setting and advances to the next item.
- The **No** button: rejects entry into the displayed menu.
Rejects the displayed menu and moves on to the next selection.
- The **Back** button: moves backwards to the previous menu.
Returns to the previous displayed menu or selection.
- The **Exit** button: exits from user menu to the active weighing mode.

For menu items which need to set numbers such as the scale capacity, the current number is displayed with all digits flashing. To revise:

1. Press the **No** button to begin editing.



2. The first digit is displayed flashing.



3. Press the **No** button to increase the digit or press the **Yes** button to accept the digit and move to the next one.



Note: press the **Back** button can decrease the digit.


4. Repeat this process for all digits.



5. Press the **Yes** button when the last digit has been set.



6. The new setting is displayed with all digits flashing.
Press the **Yes** button to accept the setting or press the **No** button to resume editing.



7. To end the current menu selection, press the **Yes** button to advance to the next menu, or press the **No** button to return to the top of the current menu.

4.2 Calibration Menu

Enter the calibration menu **C.A.L** to perform calibrations.

4.2.1 Initial Calibration

When the scale is operated for the first time, a zero and span calibration are recommended to ensure accurate weighing results.

Before performing the calibration, be sure to have the appropriate calibration weights as listed in table 4-1. Ensure that the LFT switch/calibration lock is set to the unlocked position.

You can also adjust the GEO setting according to your location. For detailed GEO information, please check the **Geo Code Adjustment** section below.

Table 4-1 Suggested Span Calibration Mass (Sold Separately)

| Max Capacity (kg) | Mass* (kg) | Max Capacity (lb) | Mass* (lb) |
|-------------------|------------|-------------------|------------|
| 3 kg | 3 kg | 6 lb | 6 lb |
| 6 kg | 6 kg | 12 lb | 12 lb |
| 15 kg | 15 kg | 30 lb | 30 lb |
| 30 kg | 30 kg | 60 lb | 60 lb |
| 60 kg | 60 kg | 120 lb | 120 lb |
| 150 kg | 150 kg | 300 lb | 300 lb |

Note: The calibration unit is consistent with the capacity unit.

4.2.2 Zero Calibration [ZEr0]

Zero calibration uses one calibration point. The zero calibration point is established with no weight on the scale. Use this calibration method to adjust for a different static load without affecting the span or linearity calibration.

Calibration procedures:

1. Long press the **Menu** button until you see **00.E.N.U.**
2. Release the button and wait for the display to show **C.A.L**. Press the **Yes** button.
3. The display shows **ZEr0**. Press the **Yes** button.
4. **0** kg and the calibration unit are flashing on the display. With no weight on the pan, press the **Yes** button to establish the zero point.
5. The display shows **--C--**, and then **-dONE-** when the Zero calibration is finished.

Note:

If zero calibration is failed or if after 40 seconds the calibration is still not successful, **CAL E** is displayed for 3 seconds and the previous calibration data will be restored.

6. Then the display shows **SPAN**. Press the **Exit** button to exit.

4.2.3 Span Calibration [SPAN]

Span calibration uses one calibration point. It is established with a calibration mass placed on the scale.

Note: Span calibration should be performed after zero calibration.

Calibration procedures:

1. Long press the **Menu** button until you see **00.E.N.U.**
2. Release the button and wait for the display to show **C.A.L**. Press the **Yes** button.
3. Short press the **No** button to navigate until you see **SPAN**. Press the **Yes** button.
4. The calibration point and the unit are flashing on the display based on the scale capacity and unit set in the menu. (e.g. **030.000** kg) If you do not need to change the calibration point, skip to step 6.
5. To change the calibration point:
 - a) Short press the **No** button several times until the desired number appears.
Note: press the **Back** button can decrease the digit.
 - b) Short press the **Yes** button to accept the number and move on to the next digit.

- c) Repeat the process until all the digits are correct.
- d) Press the **Yes** button to accept calibration point. It is flashing on the display.
6. Place a calibration mass of the specified weight on the pan and press the **Yes** button.
7. The display shows **--[--**, and then **-dONE-** when the calibration is finished.
8. Then the display shows **L 00**. Press the **Exit** button to exit.

Note:

- If calibration is failed, **CAL E** is displayed for 3 seconds and the previous calibration data is restored.
- If after waiting for 40 seconds the calibration is still not successful, **CAL E** is displayed for 3 seconds and the previous calibration data is restored.

4.2.4 Linearity Calibration [L 00]

Linearity calibration uses 3 calibration points. The full calibration point is established with a weight on the pan. The mid calibration point is established with a weight equal to half of the full calibration weight on the pan. The zero calibration point is established with no weight on the pan. The full calibration and mid calibration points can be altered by users during the calibration procedure.

Calibration procedures:

1. Long press the **Menu** button until you see **00.E.N.U.**
2. Release the button and wait for the display to show **C.A.L.** Press the **Yes** button.
3. Short press the **No** button several times to navigate until you see **L 00**. Press the **Yes** button.
4. **0** kg and the calibration unit are flashing on the display. With no weight on the pan, press the **Yes** button to establish the zero point. The display shows **--[--**.
5. Then the first calibration point and the unit are flashing on the display based on the scale capacity and unit you set in the setup menu. (For example, **0 15.000** kg). If you do not need to change the calibration point, skip to step 7.
6. To change the calibration point:
 - a) Short press the **No** button several times until the desired number appears.
Note: press the **Back** button can decrease the digit.
 - b) Short press the **Yes** button to accept the number and move on to the next digit.
 - c) Repeat the process until all the digits are correct.
 - d) Press the **Yes** button to accept calibration point. It is flashing on the display.
7. Place a calibration mass of the specified weight on the pan and press the **Yes** button. The display shows **--[--**.
8. The second calibration point and the unit are flashing on the display based on the capacity and unit you set in the setup menu. (For example, **030.000** kg)

Note:

If after waiting for 40s the calibration is still not successful, **CAL E** is displayed for 3 seconds and the previous calibration data is restored.

9. Repeat step 6 and 7.
10. The display shows **--[--**, and then **-dONE-** when the Linearity calibration is finished.
11. After that the display shows **GEO**. Press the **Exit** button to exit.

4.2.5 GEO Code Adjustment [GEO]

Geographical Adjustment Factor (GEO) code is used to adjust the calibration based on the current location. Settings from 0 to 31 are available with 12 being the default.

Please refer to the **Table of Geo Code Values** section in the **Technical Data** chapter to determine the GEO factor that corresponds to the indicator's location.

To set the GEO factor:

1. Long press the **Menu** button until you see **00.E.N.U.**
2. Release the button and wait for the display to show **C.A.L.** Press the **Yes** button.
3. Short press the **No** button several times to navigate until you see **GEO**. Press the **Yes** button.
4. The Geo point is flashing on the display (For example, **12**).

5. Short press the **No** button several times until the desired GEO number appears. Press the **Yes** button to accept.
Note: Press the **Back** button can decrease the digit.
6. Then the display shows **C.L.E5L**. Press the **Exit** button to exit.

4.2.6 Calibration Test [C.L.E5L]

Calibration test procedures:

1. Long press the **Menu** button until you see **M.N.E.N.U.**
2. Release the button and wait for the display to show **C.R.L.** Press the **Yes** button.
3. Short press the **No** button several times to navigate until you see **C.L.E5L**. Press the **Yes** button.
4. **0** and the calibration unit are flashing on the display based on the capacity and unit you set in the setup menu. With no weight on the pan, press the **Yes** button to establish the zero point.
5. The display shows **--C--** while the zero point is recorded.
6. The calibration weight and the unit of the last time are flashing on the display. (For example, **0 15.000 kg**).
6. To change the test calibration weight:
 - a) Short press the **No** button several times until the desired number appears.
Note: press the **Back** button can decrease the digit.
 - b) Short press the **Yes** button to accept the number and move on to the next digit.
 - c) Repeat the process until all the digits are correct.
 - d) Press the **Yes** button to accept the calibration point. It is flashing on the display.
7. Place the specified test weight on the pan and press the **Yes** button.
8. The difference between the calibration data and the test weight is flashing on the display. (For example, **0.0 10 kg**). If the indicator is connected to a printer or other devices, the result will be printed.
Note: the printed result will appear as below:
Example:


```

----- Cal Test -----
New Cal:6.0000kg
Old Cal:6.0000kg
Diff Cal:0.0000kg
Wt. ID:_____
----- End -----

```
9. After 5 seconds, the test ends and the scale returns to the active weighing mode, displaying the current weight.

4.2.7 End Cal [End]

When **End** is displayed, press the **Yes** button to exit this menu and advance to the next sub-menu, or press the **No** button to advance to the first menu item in the this sub-menu.

4.3 Setup Menu

Enter this menu **5.E.t.U.P** to set scale parameters. Default settings are in **bold**.

| Menu | Sub-Menu | Sub-Menu (in segment) | Options | Options (in segment) |
|----------------------------|------------------|-----------------------|---------------------------------------|------------------------|
| Setup 5.E.t.U.P | Reset | rESEt | no, yes | NO. YES |
| | Capacity Unit | C.Ut It | kg, lb | / |
| | Range | rRNGE | Single, Dual | SINGLE, dUAL |
| | > 1 < Capacity | CRP | 0.1-99999.9 | / |
| | > 1 < Graduation | GrAd | 0.0001~100 | / |
| | > 2 < Capacity | CRP | 0.1-99999.9 | / |
| | > 2 < Graduation | GrAd | 0.0001~100 | / |
| | Power On Zero | P.ZEr0 | Off, On | OFF, ON |
| | Power On Unit | P.Ut It | Auto , g, kg, lb, oz, lb:oz, t | AUTO |
| | Auto Tare | A.tARt | Off, On, Accept | OFF, ON, ACCEPt |
| | End | End | / | / |

Note: / refers to not applicable in the table above.

Reset [**rESEt**]

Reset the Setup menu to factory defaults.

NO = do not reset
YES = reset

Capacity Unit [**C.Ut It**]

Select the unit used for calibration.

kg
lb

Range [**rRNGE**]

Selects the number of weighing intervals.

This terminals can be configured to use single or dual interval. Each interval can be assigned its own graduation. If dual interval is selected, the graduation will change when the weight reaches the second interval.

When **Single** interval is selected, the additional parameters available are:

Capacity
 Graduation

When **Dual** interval is selected, the terminal functions with two intervals, each with its own capacity and graduation. In addition to the Interval 1 capacity and graduation parameters, the following two parameters are available:

Capacity 2
 Graduation 2

Capacity [**CRP**] / Capacity1 [**CRP 1**]

Set the capacity of the scale or the first capacity of the scale.
 0.1-99999.9

Grad [**GrAd**] / Grad1 [**GrAd 1**]

Set the scale readability or the first readability of the scale.
 0.0001~100

Capacity2 [**CRP2**]

Set the second capacity of the scale.

Grad2 [GrAd2]

Set the second readability of the scale.

Note:

- The value of graduation 2 must be larger than graduation 1, and it applies to capacity as well.
- The capacity and graduation value should be within the following range, or your setting will be unsuccessful:

$$\text{Capacity} / 30000 \leq \text{Graduation} \leq \text{Capacity} / 600$$

Power On Zero [P.2Er0]

Zero the scale at Power On.

OFF = disabled.

On = enabled.

Power On Unit [P.ON It]

Set the unit that will be displayed at Power On.

Auto = last unit in use when turned off

kg = kilograms

g = grams

lb = pounds

oz = ounces

lb:oz = pound ounces

t = metric tonne

Auto Tare [A.tArE]

Set the automatic tare feature.

OFF = automatic tare is disabled.

On = the first stable gross weight is tared. The tared value will be cleared when the indicator returns to gross zero.

Accept = stable gross weights within the Accept limits are tared (in Check mode only).

4.4 Readout Menu

Enter this menu to set user preferences. Default settings are in **bold**.

| Menu | Sub-Menu | Sub-Menu (in segment) | Options | Options (in segment) |
|-------------------------------------|------------------|-----------------------|----------------------------------|-----------------------------------|
| Read Out (r.E.R.d) | Reset | rESEt | no, yes | nO, yES |
| | Stability | StAbLE | 0.5d, 1d , 2d, 5d | 0.5d, 1d , 2d, 5d |
| | Zero Range | ZErO | 2%, 100% | 2, 100 |
| | Filter Level | F ILtEr | Low, Medium , High | LOW, MEd , H IGH |
| | Auto Zero Track | AZt | Off, 0.5d , 1d, 3d | OFF, 0.5d , 1d, 3d |
| | Back Light | b.L lGHt | Off, On, Auto | OFF, ON, AutO |
| | Back Light Color | b.COLOr | Green, Yellow, Red, Amber | GrEEEn, rEd, yELLow, AmBER |
| | Screen Saver | ScR-EEr | Off, 1min , 2min, 5min | OFF, 1 , 2, 5 |
| | Auto Off | A.OFF | Off , 1min, 5min, 10min | OFF , 1, 5, 10 |
| | PWM.SAVE | P.SAVEr | ON , OFF | ON , OFF |
| | CEC | CEC | ON, OFF | ON, OFF |
| | End | End | / | / |

Note: / refers to not applicable in the table above.

Reset [rESEt]

Reset the readout menu to factory defaults.

nO = do not reset.
yES = reset

Stability [StAbLE]

Set the amount reading can vary before the stability symbol turns off.

0.5d = 0.5 of a scale division
1d = 1 scale division
2d = 2 scale divisions
5d = 5 scale divisions

Zero [ZErO]

Set the percentage of scale capacity that can be zeroed.

2% = zero range is within +/-2%
100% = zero range is within +/-100%

Filter [F ILtEr]

Set the amount of signal filtering.

LOW = faster stabilization time with less stability.
MEd = normal stabilization time with normal stability.
HIGH = slower stabilization time with more stability.

AZT [AZt]

Set the automatic zero tracking feature.

OFF = disabled
0.5d = the display will maintain zero until a change of 0.5 of a divisions per second has been exceeded.
1d = the display will maintain zero until a change of 1 division per second has been exceeded.
3d = the display will maintain zero until a change of 3 divisions per second has been exceeded.

Backlight [b.L lGHt]

Set the display backlight feature.

OFF = backlight is disabled.

- ON** = backlight is enabled and always on.
AUTO = backlight is disabled after 20 seconds of no activity.

Backlight Color [b.COLOR]

Set the display backlight color.

- AMBER** = backlight color is amber.
GREEN = backlight color is green.
RED = backlight color is red.
YELLOW = backlight color is yellow.

Screen Saver [S.SEE]

Set whether the screen saver is enabled after the selected time period.

- OFF** = screen saver is disabled
1 = the screen saver is enabled after 1 minute of no activity.
2 = the screen saver is enabled after 2 minutes of no activity.
5 = the screen saver is enabled after 5 minutes of no activity.

Auto Off [A.OFF]

Set whether the display enters sleep mode after the selected time period.

- OFF** = disabled
1 = the display enters sleep mode after 1 minute of no activity.
5 = the display enters sleep mode after 5 minutes of no activity.
10 = the display enters sleep mode after 10 minutes of no activity.

PWM.SAVE [P.SAVE]

Set whether to enable power saving mode after the scale enters standby mode. If it is enabled, it will take about 3 seconds before the indicator returns to weighing when weight is changed on the pan or you press the indicator's buttons.

- ON** = power saving is enabled.
OFF = power saving is disabled.

CEC [CEC]

Set whether to enable California Energy Commission function. When enabled, the energy plan complies with the California Energy Commission regulation.

- ON** = CEC is enabled.
OFF = CEC is disabled.

End Readout [End]

Advance to the next menu or return to the top of the current menu.

4.5 Unit Menu

Enter this menu **U.N. 1.1** to activate the desired units.

Reset
Gram (g)
Kilogram (kg)
Pound (lb)
Ounce (oz)
Pound:Ounce (lb:oz)
Metric Tonne (t)
End

Note:

- Available units vary by model. In addition, due to national laws, the indicator may not include some of the units listed.
- If the security switch is turned on, the Units menu will be locked at their current setting.
- When the scale capacity is set to be more than 1000 kg, **Metric Tonne (t)** unit will appear in the Unit menu.

4.6 Communication

Enter this menu to define external communication methods and to set printing parameters. Data may be output to either a printer or PC. Factory default settings are shown in bold.

4.6.1 RS232 Menu

Enter this menu to define communication parameters.

| Menu | Sub-Menu | Sub-Menu (in segment) | Options | Options (in segment) |
|-----------------------------|---------------|-----------------------|---|--------------------------------------|
| RS232 (r.5.2.3.2) | Baud Rate | bAUd | 300, 600, 1200, 2400, 4800, 9600 , 19200, 38400, 57600 | / |
| | Parity | PAR 1EY | 7 Even, 7 Odd, 7 None, 8 None | 7 EwEN, 7 Odd, 7 none, 8 none |
| | Stop Bit | StOP | 1 bit , 2 bit | 1 b 1E , 2 b 1E |
| | Handshake | H.SHAKE | None , Xon/Xoff | none , ON-OFF |
| | Alt Print CMD | ALt.P | 'A' ~ 'Z', P | / |
| | Alt Tare CMD | ALt.t | 'A' ~ 'Z', T | / |
| | Alt Zero CMD | ALt.z | 'A' ~ 'Z', Z | / |
| | Reset | rESEt | no , yes | nO , yES |
| | End | End | / | / |

Note: / refers to not applicable in the table above.

Reset [**rESEt**]

Reset the RS232 menu to factory defaults.

nO = do not reset.
yES = reset

Baud Rate [**bAUd**]

Set the baud rate (bits per second).

300 = 300 bps
600 = 600 bps
1200 = 1200 bps
2400 = 2400 bps
4800 = 4800 bps
9600 = 9600 bps
19200 = 19200 bps
38400 = 38400 bps
57600 = 57600 bps

Parity [PARITY]

Set the data bits and parity.

- 7 EVEN = 7 data bits, even parity
- 7 ODD = 7 data bits, odd parity
- 7 NONE = 7 data bits, no parity
- 8 NONE = 8 data bits, no parity

Stop bit [STOP]

Set the number of stop bits.

- 1 bit = 1 stop bits
- 2 bit = 2 stop bits

Handshake [HANDSHAKE]

Set the flow control method. Hardware handshaking is only available for COM1 menu.

- NONE = no handshaking
- ON-OFF = XON/XOFF software handshaking

Alternate Print command [ALT.P]

Set the alternate command character for Print.

Settings of A (a) to Z (z) are available. The default setting is P.

Alternate Tare command [ALT.T]

Set the alternate command character for Tare.

Settings of A(a) to Z(z) are available. The default setting is T.

Alternate Zero command [ALT.Z]

Set the alternate command character for Zero.

Settings of A (a) to Z (z) are available. The default setting is Z.

End [End]

Advance to the next menu or return to the top of the current menu.

4.6.2 Print Menu

Enter this menu to set printing parameters. Default settings are **bold**.

| Menu | Sub-Menu | Sub-Menu (in segment) | Options | Options (in segment) |
|----------------------------------|-----------------------------|-----------------------|---|---|
| Print (P.r. t.n.t. t)/ | Assignment | ASSIGN | Demand , Auto On Stable, Auto On Accept, Interval(seconds), MT-Continuous, OH-Continuous, SICS | DEMAND , ON.StAb, ON.ACCEP, IntEr, rnt.cOn, OH.cOn, SICS |
| | Stable Weight Only [Demand] | StAbLE | Off , On(LFT Force On) | OFF , ON |
| | Mode [Auto On Stable] | rnOdE | Load , Load and Zero | LOAD , LOAD:Zr |
| | Time [Interval (seconds)] | t nTt | 1~5000 | / |
| | Checksum [MT-Continuous] | .SbTt | On, Off | ON, OFF |
| | Link to [OH-Continuous] | L nTtO | Off , Custom 1, Custom 2 | OFF . CUSr 1, CUSr2 |
| | Template | tErnT | Custom 1 , Custom 2 | CUSr 1 , CUSr2 |
| | Reset | rESEt | no , yes | NO, YES |
| | End | End | / | / |

Note: / refers to not applicable in the table above.

Reset [rESEt]

Reset the Print menu to factory defaults.

NO = do not reset.
YES = reset

Assignment [ASSIGN]

Demand [DEMAND]

If **Demand** is selected, the sub-menu **Stable Only** will display.

Set the printing criteria.

OFF = values are printed immediately, regardless of stability.
ON = values are printed only when the stability criteria is met.

Auto On Stable [ON.StAb]

If **Auto On Stable** is selected, the sub-menu **Mode** will display.

Set the printing mode.

LOAD = prints when the displayed load is stable.
LOAD:Zr = prints when the displayed load and zero reading are stable.

Auto On Accept [ON.ACCEP]

If **Auto On Accept** is selected and the weighing mode is **Check**, values will be printed when the weight is accepted.

ON.ACCEP = printing occurs each time the display is within the Accept range and stability criteria is met.

Interval [IntEr]

If **Interval** is selected, the sub-menu **Time** will display.

IntEr = printing occurs at the defined time interval.
Settings of 1 to 5000 seconds are available. Default is 1.
Printing occurs at the defined time interval.

MT-Continuous [ጠግኔ.ርፀገ]

If **MT-Continuous** is selected, the print output will be in the **MT-Continuous** format.

ጠግኔ.ርፀገ = printing occurs continuously.

Note: Refer to Appendix A for **MT-Continuous** format.

ር.5ህጥግ

Off = disabled

On = enabled

OH-Continuous [ዐዛ.ርፀገ]

If **OH-Continuous** is selected, the print output will be in the **OH-Continuous** format.

Note: Refer to Appendix D for **OH-Continuous** format.

ዐዛ.ርፀገ = printing occurs continuously.

ፈ ጠግኔ

OFF = disabled

ርህኔ 1 = print using custom 1 template.

ርህኔ 2 = print using custom 2 template.

SICS [5 ሳር5]

OFF = disable MT-SICS command

ዐገ = enable MT-SICS command

Note: Refer to Appendix B for **SICS** commands.

End Print [ፎገፈ]

Advance to the next menu or return to the top of the current menu.

Template [ፎፎጥፎ]

This sub-menu is used to define the format of the data output to a printer or computer.

ርህኔ 1 = customized printout format.

ርህኔ 2 = customized printout format.

Print template example:


0.000 kg

0.300 kg G

0.000 kg N

0.100 kg T

Connect the indicator to OHAUS ScaleMate software on a PC via the RS232 (or USB or Ethernet optional ports). To customize print template, you need to go to the ScaleMate software, Select **Print Template** on the top bar, and then double click items in the left column to select which ones you want to put in your print template.



Note: Contact an authorized OHAUS dealer to obtain the ScaleMate software and learn more about the software's other functions.

Alternatively, you can also input the index number of the print items in the middle column directly to customize your print template in the software, using $\$[XXXX]!$ format. XXXX refers to the index number of each print item. Please check the following table for each item's index number.

| Index Number | Print Items |
|--------------|--|
| 5000 | Result |
| 5001 | Gross |
| 5002 | Net |
| 5003 | Tare |
| 5004 | Displayed Weight |
| 5005 | Displayed Digit |
| | |
| 5300 | Mode |
| 5301 | Information (APW value in Counting; Under and Over Value in Check; Totalization result in Total) |
| | |
| 5403 | Indicator's Serial Number |
| | |
| 5900 | New Line |
| 5901 | End of Template |
| 5902 | Header Line 1 |
| 5903 | Header Line 2 |
| 5904 | Header Line 3 |
| 5905 | Header Line 4 |
| 5906 | Header Line 5 |

4.6.3 USB Configuration

Please refer to USB Configuration in the *Defender™ 3000 USB Interface Instruction Manual*.

4.6.4 Ethernet Configuration

Please refer to Configuration in the *Defender™ 3000 Ethernet Interface Instruction Manual*.

4.7 Lock Button Configuration

This menu **L.O.C.K.** is used to lock access to certain buttons. When you select ON for one selection, the associated button press will be ignored.

If you select **Lock All Keys**, you will lose function of all buttons.

If the **Menu** button has been locked, long press the **Menu** button for 15 seconds until you see **UN.LOCK**. Press the **Yes** button to confirm.

| Item | Available Settings (bold is the default settings) |
|-----------------------------------|--|
| Lock All Keys [L.ALL] | OFF, ON |
| Lock Off Key [L.OFF] | OFF, ON |
| Lock Zero Key [L.ZERO] | OFF, ON |
| Lock Print Key [L.PRINT] | OFF, ON |
| Lock Unit Key [L.UNIT] | OFF, ON |
| Lock Mode Key [L.MODE] | OFF, ON |
| Lock Menu Key [L.MENU] | OFF, ON |
| Lock Tare key [L.TARE] | OFF, ON |
| Reset | NO, YES |

5. LEGAL FOR TRADE

When the indicator is used in trade or a legally controlled application, it must be set up, verified and sealed in accordance with local weights and measures regulations. It is the responsibility of the purchaser to ensure that all pertinent legal requirements are met.

5.1 Settings

Before verification and sealing, perform the following steps:

1. Verify that the menu settings meet the local weights and measures regulations.
2. Perform a calibration as explained in **Calibration Menu** section.
3. Turn the indicator off.

To turn the security switch on:

1. Disconnect power from the indicator and open the housing as demonstrated in **Open the Housing** section.

Note:

- Remove dry batteries for i-DT33P if used.
 - Remove the lead-acid battery if it is included in your i-DT33P model. Please refer to **Open the Housing** section **i-DT33P (with Lead-acid Battery)** sub-section for instruction.
 - Remove the first layer built-in housing including the lead-acid battery for i-DT33XW. Please refer to **Scale Base without EasyConnect™** section for instruction.
2. Turn the position of the security switch (S1) to ON. Refer to the following two graphics for the location of S1.




Figure 5-1 i-DT33P Security Switch (S1)
Location




Figure 5-2 i-DT33XW Security Switch (S1)
Location

3. Close the housing. Re-install the lead-acid battery/dry batteries mentioned in step 1.
4. Reconnect the power and turn the indicator on.

5.2 Verification

The local weights and measures official or authorized service agent must perform the verification procedure.

5.3 Sealing

After the scale has been verified, it must be sealed to prevent undetected access to the legally controlled settings. Refer to the illustrations below for sealing methods.




Figure 5-3. i-DT33P Wire Sealing




Figure 5-4. i-DT33P paper Sealing




Figure 5-5. i-DT33XW Wire Sealing




Figure 5-6. i-DT33XW Paper Sealing

For the sealing of the scale base, when the i-DT33P or i-DT33XW indicator is connected to an OHAUS Defender 3000 series base boasting EasyConnect™ function, it has a memory module on the load cell cable. The connection cable is sealed with software pairing, so no hardware sealing of the cable is needed. Once the indicator or the base is replaced by a new one, an error message (**Error 8.9**) will be shown on the indicator's display.

When the i-DT33P or i-DT33XW indicator is connected to a base that does not include a memory module, but supports load cell adapter connection, the connection between the indicator and the base shall be sealed by using a connector cover (P/N: 30538022), sealing sticker or wire seal.

i-DT33P




Figure 5-7. i-DT33P Sealing (Connecting cable with connector and memory module)




Figure 5-8. i-DT33P Sealing (Connecting cable with connector and without memory module)

i-DT33XW




Figure 5-9. i-DT33XW Sealing (Connecting cable with connector and memory module)




Figure 5-10. i-DT33XW Sealing (Connecting cable with connector and without memory module)

6. MAINTENANCE

CAUTION: DISCONNECT THE UNIT FROM THE POWER SUPPLY BEFORE CLEANING.

6.1 Cleaning

For i-DT33P, the housing may be cleaned with a cloth dampened with a mild detergent if necessary.

For i-DT33XW, use approved cleaning solutions for the stainless-steel Indicator housing and rinse with water. Dry thoroughly.



WARNING: Electric Shock Hazard. Disconnect the equipment from the power supply before cleaning. Make sure that no liquid enters the interior of the instrument.



Attention: Do not use solvents, harsh chemicals, ammonia or abrasive cleaning agents.

6.2 Troubleshooting

TABLE 6-1 Troubleshooting

| SYMPTOM | PROBABLE CAUSE (s) | REMEDY |
|---|--|---|
| EEP Error | EEPROM Checksum Error | Corrupted EEPROM data |
| Unable to turn on the indicator. | <ol style="list-style-type: none"> 1. Power cord not plugged in or properly connected. 2. Power outlet not supplying electricity. 3. Battery discharged. 4. Other failure. | <ol style="list-style-type: none"> 1. Check power cord connections. Make sure power cord is plugged in properly into the power outlet. 2. Check power source. 3. Recharge battery. 4. Service required. |
| Cannot zero the scale, or will not zero when turned on the indicator. | <ol style="list-style-type: none"> 1. Weights on the pan exceeds allowable limits. 2. Weight is not stable. 3. Load cell is damaged. | <ol style="list-style-type: none"> 1. Remove weights on the pan. 2. Wait for weight to become stable, check area around the scale and weight on scale for excessive vibration or movement, or increase filtering. 3. Service required. |
| Unable to calibrate. | <ol style="list-style-type: none"> 1. LFT security switch is turned on. 2. Incorrect value for calibration mass. | <ol style="list-style-type: none"> 1. Turn the LFT security switch off. 2. Use correct calibration mass. |
| Cannot display weight in desired weighing unit. | Unit is disabled. | Enable unit in the Units Menu. Refer to Unit Menu section for help. |
| Cannot change menu settings. | The Menu button has been locked. | <ol style="list-style-type: none"> 1. Enable the Menu button in the L.O.C.F. Menu. 2. The LFT security switch may need to be switched off. |
| Error 8.1 | Weight reading exceeds Power On Zero limit. | <ol style="list-style-type: none"> 1. Remove weight from the pan. 2. Recalibrate the scale. |
| Error 8.2 | Weight reading below Power On Zero limit. | <ol style="list-style-type: none"> 1. Add weight to the pan. 2. Recalibrate the scale. |
| Error 8.3 | Weight reading exceeds Overload limit. | Reduce weight on the pan. |
| Error 8.4 | Weight reading below Underload limit. | <ol style="list-style-type: none"> 1. Add weight to the pan. 2. Recalibrate the scale. |
| Error 8.8 | Factory calibration data in the EasyConnect™ module on load cell cable is not valid under LFT off status. | Calibrate the scale. |
| Error 8.9 | Fail to read serial number from the EasyConnect™ module or the serial number does not match the LFT ON status. | <ol style="list-style-type: none"> 1. Break the seal or replace the original base/indicator. 2. Service required. |
| Error 9.5 | Calibration data not presented. | Calibrate the scale. |
| Battery symbol flashing | Low battery | Replace dry batteries for i-DT33P model or recharge battery for i-DT33XW model. |
| CALE | Calibration value outside allowable limits | Use correct calibration weight. |
| REF Err | The average piece of weight (APW) on the pan is too small and less than 0.1d. | Replace a heavier batch of samples or change to a scale with readability suitable for your samples. |

Note: Please refer to the **LEGAL FOR TRADE** chapter, **Settings** section for the position of the LFT security switch for each model.

6.3 Service Information

If the troubleshooting section does not resolve your problem, contact an authorized OHAUS Service Agent. For Service assistance in the United States, call toll-free 1-800-526-0659 between 8:00 AM and 5:00 PM Eastern Standard Time. An OHAUS Product Service Specialist will be available to assist you. Outside the USA, please visit our website www.ohaus.com to locate the OHAUS office nearest you.

7. TECHNICAL DATA

7.1 Specifications

Equipment Ratings:

Indoor use only

Altitude: 2,000m

Operating temperature: -10°C to 40°C

Humidity: Maximum relative humidity 80% for temperatures up to 31 °C decreasing linearly to 50% relative humidity at 40°C.

Electrical supply: 100 - 240V~, 0.5A, 50/60Hz

Voltage fluctuations: Mains supply voltage fluctuations up to ±10% of the nominal voltage.

Overvoltage category II

(Installation category):

Pollution degree: 2

| Model | i-DT33P |
|-----------------------------------|--|
| Construction | ABS plastic housing, powder coated carbon steel bracket |
| Maximum displayed resolution | 1:30,000 |
| Maximum approved resolution | 1:10,000 or 2 × 3,000e Class III @ 1 µV/e (EC, OIML); 1:6,000 (NTEP/Measurement Canada) Class III |
| Weighing units | Kilogram, Gram, Pound, Ounce, Pound: Ounce, Tonne (Metric Tonne) |
| Modes | Weighing, Counting, Check, Totalization |
| Display | 45 mm / 1.8 in digit height LCD display with 4-color backlight |
| Check indicator | 3 color (red, green, yellow) bar |
| Keyboard | 4 button membrane keyboard |
| Auto-zero tracking | Off, 0.5 d, 1 d or 3 d |
| Load cell excitation voltage | 5VDC |
| Load cell drive | Up to 6 X 350 ohm |
| Load cell input sensitivity | Up to 3 mV/V |
| Stabilization time | 1 second |
| Power | 9 VDC, 6 dry cells, size C; 6 VDC rechargeable battery; 100-240 VAC / 50-60 Hz internal power supply (depending on models) |
| Battery life | Dry cell battery: up to 200 hours continuous use with backlight off Rechargeable battery: up to 100 hours continuous use with backlight off |
| Interface | RS232 standard, Optional USB device or Ethernet |
| Shipping dimensions | 300 x 265 x 135 mm 11.8 x 10.4 x 5.3 in |
| Product dimensions (with bracket) | 252 x 176 x 80 mm / 9.9 x 6.9 x 3.1 in |
| Approx. net weight | 1.3 kg / 2.9 lb |
| Approx. shipping weight | 1.6 kg / 3.5 lb |
| Operating temperature range | -10°C to 40°C / 14°F to 104°F |

| | |
|-----------------------------------|---|
| Model | i-DT33XW |
| Construction | 304 stainless steel housing, 304 stainless steel bracket |
| Protection | IP66 |
| Maximum displayed resolution | 1:30,000 |
| Maximum approved resolution | 1:10,000 or 2 × 3,000e Class III @ 1 µV/e (EC, OIML) 1:6,000 (NTEP/M Measurement Canada) Class III |
| Weighing units | Kilogram, Gram, Pound, Ounce, Pound: Ounce, Tonne (Metric Tonne) |
| Modes | Weighing, Counting, Check, Totalization |
| Display | 45 mm / 1.8 in digit height LCD display with 4-color backlight |
| Check indicator | 3 color (red, green, yellow) bar |
| Keyboard | 4 button membrane keyboard |
| Auto-zero tracking | Off, 0.5 d, 1 d or 3 d |
| Load cell excitation voltage | 5VDC |
| Load cell drive | Up to 6 X 350 ohm |
| Load cell input sensitivity | Up to 3 mV/V |
| Stabilization time | 1 second |
| Power | 6 VDC rechargeable battery; 100-240 VAC / 50-60 Hz internal power supply |
| Battery life | Up to 100 hours continuous use with backlight off |
| Interface | RS232 standard, Optional USB device or Ethernet |
| Shipping dimensions | 300 x 265 x 135 mm 11.8 x 10.4 x 5.3 in |
| Product dimensions (with bracket) | 260 x 204 x 74 mm / 10.2 x 8.0 x 2.9 in |
| Approx. net weight | 3.1 kg / 6.8 lb |
| Approx. shipping weight | 3.4 kg / 7.5 lb |
| Operating temperature range | -10°C to 40°C / 14°F to 104°F |






7.2 Table of Geo Code Values

TABLE 7-1 GEO CODES

| | | Elevation in meters | | | | | | | | | | |
|----------|--------|---------------------|------|------|------|------|------|------|------|------|-------|-------|
| | | 0 | 325 | 650 | 975 | 1300 | 1625 | 1950 | 2275 | 2600 | 2925 | 3250 |
| | | 325 | 650 | 975 | 1300 | 1625 | 1950 | 2275 | 2600 | 2925 | 3250 | 3575 |
| | | Elevation in feet | | | | | | | | | | |
| | | 0 | 1060 | 2130 | 3200 | 4260 | 5330 | 6400 | 7460 | 8530 | 9600 | 10660 |
| | | 1060 | 2130 | 3200 | 4260 | 5330 | 6400 | 7460 | 8530 | 9600 | 10660 | 11730 |
| Latitude | | GEO value | | | | | | | | | | |
| 0°00' | 5°46' | 5 | 4 | 4 | 3 | 3 | 2 | 2 | 1 | 1 | 0 | 0 |
| 5°46' | 9°52' | 5 | 5 | 4 | 4 | 3 | 3 | 2 | 2 | 1 | 1 | 0 |
| 9°52' | 12°44' | 6 | 5 | 5 | 4 | 4 | 3 | 3 | 2 | 2 | 1 | 1 |
| 12°44' | 15°06' | 6 | 6 | 5 | 5 | 4 | 4 | 3 | 3 | 2 | 2 | 1 |
| 15°06' | 17°10' | 7 | 6 | 6 | 5 | 5 | 4 | 4 | 3 | 3 | 2 | 2 |
| 17°10' | 19°02' | 7 | 7 | 6 | 6 | 5 | 5 | 4 | 4 | 3 | 3 | 2 |
| 19°02' | 20°45' | 8 | 7 | 7 | 6 | 6 | 5 | 5 | 4 | 4 | 3 | 3 |
| 20°45' | 22°22' | 8 | 8 | 7 | 7 | 6 | 6 | 5 | 5 | 4 | 4 | 3 |
| 22°22' | 23°54' | 9 | 8 | 8 | 7 | 7 | 6 | 6 | 5 | 5 | 4 | 4 |
| 23°54' | 25°21' | 9 | 9 | 8 | 8 | 7 | 7 | 6 | 6 | 5 | 5 | 4 |
| 25°21' | 26°45' | 10 | 9 | 9 | 8 | 8 | 7 | 7 | 6 | 6 | 5 | 5 |
| 26°45' | 28°06' | 10 | 10 | 9 | 9 | 8 | 8 | 7 | 7 | 6 | 6 | 5 |
| 28°06' | 29°25' | 11 | 10 | 10 | 9 | 9 | 8 | 8 | 7 | 7 | 6 | 6 |
| 29°25' | 30°41' | 11 | 11 | 10 | 10 | 9 | 9 | 8 | 8 | 7 | 7 | 6 |
| 30°41' | 31°56' | 12 | 11 | 11 | 10 | 10 | 9 | 9 | 8 | 8 | 7 | 7 |
| 31°56' | 33°09' | 12 | 12 | 11 | 11 | 10 | 10 | 9 | 9 | 8 | 8 | 7 |
| 33°09' | 34°21' | 13 | 12 | 12 | 11 | 11 | 10 | 10 | 9 | 9 | 8 | 8 |
| 34°21' | 35°31' | 13 | 13 | 12 | 12 | 11 | 11 | 10 | 10 | 9 | 9 | 8 |
| 35°31' | 36°41' | 14 | 13 | 13 | 12 | 12 | 11 | 11 | 10 | 10 | 9 | 9 |
| 36°41' | 37°50' | 14 | 14 | 13 | 13 | 12 | 12 | 11 | 11 | 10 | 10 | 9 |
| 37°50' | 38°58' | 15 | 14 | 14 | 13 | 13 | 12 | 12 | 11 | 11 | 10 | 10 |
| 38°58' | 40°05' | 15 | 15 | 14 | 14 | 13 | 13 | 12 | 12 | 11 | 11 | 10 |
| 40°05' | 41°12' | 16 | 15 | 15 | 14 | 14 | 13 | 13 | 12 | 12 | 11 | 11 |
| 41°12' | 42°19' | 16 | 16 | 15 | 15 | 14 | 14 | 13 | 13 | 12 | 12 | 11 |
| 42°19' | 43°26' | 17 | 16 | 16 | 15 | 15 | 14 | 14 | 13 | 13 | 12 | 12 |
| 43°26' | 44°32' | 17 | 17 | 16 | 16 | 15 | 15 | 14 | 14 | 13 | 13 | 12 |
| 44°32' | 45°38' | 18 | 17 | 17 | 16 | 16 | 15 | 15 | 14 | 14 | 13 | 13 |
| 45°38' | 46°45' | 18 | 18 | 17 | 17 | 16 | 16 | 15 | 15 | 14 | 14 | 13 |
| 46°45' | 47°51' | 19 | 18 | 18 | 17 | 17 | 16 | 16 | 15 | 15 | 14 | 14 |
| 47°51' | 48°58' | 19 | 19 | 18 | 18 | 17 | 17 | 16 | 16 | 15 | 15 | 14 |
| 48°58' | 50°06' | 20 | 19 | 19 | 18 | 18 | 17 | 17 | 16 | 16 | 15 | 15 |
| 50°06' | 51°13' | 20 | 20 | 19 | 19 | 18 | 18 | 17 | 17 | 16 | 16 | 15 |
| 51°13' | 52°22' | 21 | 20 | 20 | 19 | 19 | 18 | 18 | 17 | 17 | 16 | 16 |
| 52°22' | 53°31' | 21 | 21 | 20 | 20 | 19 | 19 | 18 | 18 | 17 | 17 | 16 |
| 53°31' | 54°41' | 22 | 21 | 21 | 20 | 20 | 19 | 19 | 18 | 18 | 17 | 17 |
| 54°41' | 55°52' | 22 | 22 | 21 | 21 | 20 | 20 | 19 | 19 | 18 | 18 | 17 |
| 55°52' | 57°04' | 23 | 22 | 22 | 21 | 21 | 20 | 20 | 19 | 19 | 18 | 18 |
| 57°04' | 58°17' | 23 | 23 | 22 | 22 | 21 | 21 | 20 | 20 | 19 | 19 | 18 |
| 58°17' | 59°32' | 24 | 23 | 23 | 22 | 22 | 21 | 21 | 20 | 20 | 19 | 19 |
| 59°32' | 60°49' | 24 | 24 | 23 | 23 | 22 | 22 | 21 | 21 | 20 | 20 | 19 |
| 60°49' | 62°00' | 25 | 24 | 24 | 23 | 23 | 22 | 22 | 21 | 21 | 20 | 20 |
| 62°00' | 63°30' | 25 | 25 | 24 | 24 | 23 | 23 | 22 | 22 | 21 | 21 | 20 |
| 63°30' | 64°55' | 26 | 25 | 25 | 24 | 24 | 23 | 23 | 22 | 22 | 21 | 21 |
| 64°55' | 66°24' | 26 | 26 | 25 | 25 | 24 | 24 | 23 | 23 | 22 | 22 | 21 |
| 66°24' | 67°57' | 27 | 26 | 26 | 25 | 25 | 24 | 24 | 23 | 23 | 22 | 22 |
| 67°57' | 69°35' | 27 | 27 | 26 | 26 | 25 | 25 | 24 | 24 | 23 | 23 | 22 |
| 69°35' | 71°21' | 28 | 27 | 27 | 26 | 26 | 25 | 25 | 24 | 24 | 23 | 23 |
| 71°21' | 73°16' | 28 | 28 | 27 | 27 | 26 | 26 | 25 | 25 | 24 | 24 | 23 |
| 73°16' | 75°24' | 29 | 28 | 28 | 27 | 27 | 26 | 26 | 25 | 25 | 24 | 24 |
| 75°24' | 77°52' | 29 | 29 | 28 | 28 | 27 | 27 | 26 | 26 | 25 | 25 | 24 |
| 77°52' | 80°56' | 30 | 29 | 29 | 28 | 28 | 27 | 27 | 26 | 26 | 25 | 25 |
| 80°56' | 85°45' | 30 | 30 | 29 | 29 | 28 | 28 | 27 | 27 | 26 | 26 | 25 |
| 85°45' | 90°00' | 31 | 30 | 30 | 29 | 29 | 28 | 28 | 27 | 27 | 26 | 26 |

8. COMPLIANCE

Compliance to the following standards is indicated by the corresponding mark on the product.

| Mark | Standard |
|--|--|
|  | This product complies with the applicable harmonized standards of EU Directives 2011/65/EU (RoHS), 2014/30/EU (EMC), 2014/35/EU (LVD) and 2014/31/EU (NAWI). The EU Declaration of Conformity is available online at www.ohaus.com/ce . |
|  | This product complies with the applicable statutory standards of the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012, UK Electromagnetic Compatibility Regulations 2016, Electrical Equipment (Safety) Regulations 2016 and Non-Automatic Weighing Instruments Regulations 2016. The UK Declaration of Conformity is available online at www.ohaus.com/uk-declarations . |
|  | This product complies with the EU Directive 2012/19/EU (WEEE) and 2006/66/EC (Batteries). Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment. For disposal instructions in Europe, refer to www.ohaus.com/weee . |
|  | EN 61326-1 |
|  | UL 61010-1 CAN/CSA-C22.2 No. 61010-1 |

ISED Canada Compliance Statement:

CAN ICES-003(A) / NMB-003(A)

ISO 9001 Registration

The management system governing the production of this product is ISO 9001 certified.

FCC Supplier Declaration of Conformity

Unintentional Radiator per 47CFR Part B
Trade Name: OHAUS CORPORATION
Model or Family identification: Defender 3000 series

Party issuing Supplier's Declaration of Conformity:

Ohaus Instruments (Changzhou) Co., Ltd.
2F, 22 Block, 538 West Hehai Road, Xinbei District, Changzhou
Jiangsu 213022
China
Phone: +86 519 85287270

Responsible Party – U.S. Contact Information:

Ohaus Corporation
7 Campus Drive, Suite 310
Parsippany, NJ 07054
United States
Phone: +1 973 377 9000
Web: www.ohaus.com

FCC Compliance Statement:

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

9. APPENDICES

9.1 Appendix A

MT Standard Continuous Output

A checksum character can be enabled or disabled with continuous output. The data consists of 17 or 18 bytes as shown in the standard continuous output.

Table 9-1.

Non-significant weight data and tare data digits are transmitted as spaces. The continuous output mode provides compatibility with OHAUS products that require real-time weight data. the standard continuous output. Table 9-1 shows the format for the standard continuous output.

Table 9-1: Standard Continuous Output Format

| | | Status ² | | | Indicated Weight ³ | | | | | | Tare Weight ⁴ | | | | | | | |
|-----------|------------------|---------------------|------|------|-------------------------------|---|---|---|---|-----|--------------------------|----|----|----|----|-----|-----------------|------------------|
| Character | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| Data | STX ¹ | SB-A | SB-B | SB-C | MSD | - | - | - | - | LSD | MSD | - | - | - | - | LSD | CR ⁵ | CHK ⁶ |

Continuous Output Format Notes:

1. ASCII Start of Text character (02 hex), always transmitted.
2. Status bytes A, B and C. Refer to Table 5-2, Table 5-3, and Table 5-4 for details of the structure.
3. Displayed weight. Either gross or net weight. Six digits, no decimal point or sign. Insignificant leading zeroes are replaced with spaces.
4. Tare weight. Six digits of tare weight data. No decimal point in field.
5. ASCII Carriage Return <CR> character (0D hex).
6. Checksum, transmitted only if enabled in setup. Checksum is used to detect errors in the transmission of data. Checksum is defined as the 2's complement of the seven low order bits of the binary sum of all characters preceding the checksum character, including the <STX> and <CR> characters.

Table 9-2, Table 9-3, and Table 9-4 detail the status bytes for standard continuous output.

Table 9-2: Status Byte A Bit Definitions

| Bits 2, 1, and 0 | | | |
|------------------|---|------------|------------------------|
| 2 | 1 | 0 | Decimal Point Location |
| 0 | 0 | 0 | XXXXXX00 |
| 0 | 0 | 1 | XXXXXX0 |
| 0 | 1 | 0 | XXXXXXX |
| 0 | 1 | 1 | XXXXXX.X |
| 1 | 0 | 0 | XXXXX.XX |
| 1 | 0 | 1 | XXX.XXX |
| 1 | 1 | 0 | XX.XXXX |
| 1 | 1 | 1 | X.XXXXX |
| Bits 4 and 3 | | | |
| 4 | 3 | Build Code | |
| 0 | 1 | X1 | |
| 1 | 0 | X2 | |
| 1 | 1 | X5 | |
| Bit 5 | | | Always = 1 |
| Bit 6 | | | Always = 0 |

Table 9-3: Status Byte B Bit Definitions

| Status Bits | Function |
|-------------|---|
| Bit 0 | Gross = 0, Net = 1 |
| Bit 1 | Sign, Positive = 0, Negative = 1 |
| Bit 2 | Out of Range = 1 (Over Capacity or Under Zero) |
| Bit 3 | Motion = 1, Stable = 0 |
| Bit 4 | lb = 0, kg = 1 (see also Status Byte C, bits 0, 1, 2) |
| Bit 5 | Always = 1 |
| Bit 6 | Zero Not Captured after power-up = 1 |

Table 9-4: Status Byte C Bit Definitions

| Bits 2, 1, and 0 | | | Weight Description |
|------------------|---|---|--|
| 2 | 1 | 0 | |
| 0 | 0 | 0 | lb or kg, selected by Status Byte B, bit 4 |
| 0 | 0 | 1 | grams (g) |
| 0 | 1 | 0 | metric tons (t) |
| 0 | 1 | 1 | ounces (oz) |
| 1 | 0 | 0 | not used |
| 1 | 0 | 1 | not used |
| 1 | 1 | 1 | tons (ton) |
| 1 | 1 | 1 | no units |
| Bit 3 | | | Print Request = 1 |
| Bit 4 | | | Expand Data x 10 = 1, Normal = 0 |
| Bit 5 | | | Always = 1 |
| Bit 6 | | | Always = 0 |

9.2 Appendix B

MT-SICS Commands

| | Command | Function |
|---------|---------|---|
| LEVEL 0 | @ | Reset the scale |
| | I0 | Inquiry of all available SICS commands |
| | I1 | Inquiry of SICS level and SICS versions |
| | I2 | Inquiry of scale data |
| | I3 | Inquiry of scale software version |
| | I4 | Inquiry of serial number |
| | S | Send stable weight value |
| | SI | Send weight value immediately |
| | SIR | Send weight value repeatedly |
| | Z | Zero the scale |
| | ZI | Zero immediately |
| LEVEL 1 | D | Write text into display |
| | DW | Weight display |
| | SR | Send and repeat stable weight value |
| | T | Tare |
| | TA | Tare value |
| | TAC | Clear tare |
| | TI | Tare immediately |

| | Command | Function |
|---------|---------|---|
| LEVEL 2 | C2 | Calibrate with the external calibration weight |
| | C3 | Calibrate with the internal calibration weight |
| | I10 | Inquire or set scale ID |
| | I11 | Inquire of scale type |
| | P100 | Print out on the printer |
| | P101 | Print out stable weight value |
| | P102 | Print out current weight value immediately |
| | SIRU | Send weight value in the current unit immediately and repeat |
| | SIU | Send weight value in the current unit immediately |
| | SNR | Send stable weight value and repeat after every weight change |
| | SNRU | Send stable weight value in the current unit and repeat after every weight change |
| | SRU | Send weight value in the current unit and repeat |
| | ST | After pressing the Transfer key, send the stable weight value |
| | SU | Send stable weight value in the current unit |
| LEVEL 3 | M01 | Weighing mode |
| | M02 | Stability setting |
| | M03 | Autozero function |
| | M19 | Send calibration weight |
| | M21 | Inquire/set weight unit |
| | PRN | Print out at every printer interface |
| | RST | Restart |
| | SFIR | Send weight value immediately and repeat quickly |
| | SIH | Send weight value immediately in high resolution |
| | SWU | Switch weight unit |
| | SX | Send stable data record |
| | SXI | Send data record immediately |
| | SXIR | Send data record immediately and repeat |
| | U | Switch weight unit |

9.3 Appendix C

Commands listed in the following table will be acknowledged by the scale.

The scale will return "ES" for invalid commands.

Please add `\r\n` after each command to send. (`\r` refers to `\return`; `\n` refers to `\newline`)

OHAUS Commands

| Command | Function |
|------------|--|
| P | Print displayed weight (stable or unstable). |
| IP | Print displayed weight immediately (stable or unstable). |
| CP | Print weight continuously. |
| SP | Print weight when stable. |
| Z | Same as pressing Zero Key. |
| T | Same as pressing Tare Key. |
| TA | Set/inquiry of tare weight value. <ul style="list-style-type: none"> Set: TA <i>tare value unit</i> Example: TA 5 kg Inquiry: TA |
| U | Set/inquiry current display unit. <ul style="list-style-type: none"> Set: U <i>unit ID</i> Example: U 1 Please check the following table 9-1 for the ID of each unit. Inquiry: U |
| M | Set/inquiry current application mode. <ul style="list-style-type: none"> Set: M <i>application ID</i> Example: M 0 Please check the following table 9-2 for the ID of each application. Inquiry: M |
| PSN | Print indicator's serial number. |
| CU | Set/inquiry Under Limit (only in Check mode). <ul style="list-style-type: none"> Set: CU <i>under value unit</i> Example: CU 5 kg Inquiry: CU |
| CO | Set/inquiry Over Limit (only in Check mode). <ul style="list-style-type: none"> Set: CO <i>over value unit</i> Example: CO 6 kg Inquiry: CO |
| # | Set/inquiry Counting APW. <ul style="list-style-type: none"> Set: # <i>APW value unit</i> Example: # 6 kg Inquiry: # |
| PV | Print name, software revision and LFT ON (if LFT security switch is turned ON). |
| H x "text" | Enter print output string, x = string number (1-5), "text" = string text up to 40 alphanumeric characters. |

Note:

- The italic content in each command needs to be filled with actual value.
- Space in each command is needed. Please pay attention to it when input commands.

Table 9-1 Unit ID

| Unit ID | Unit Name | Abbreviation |
|---------|--------------|--------------|
| 0 | Gram | g |
| 1 | Kilogram | kg |
| 2 | Ton | t |
| 7 | Pound | lb |
| 8 | Ounce | oz |
| 20 | Pound:Ounces | lb:oz |

Table 9-2 Application ID

| Application ID | Unit Name |
|----------------|--------------|
| 0 | Weighing |
| 1 | Counting |
| 3 | Check |
| 6 | Totalization |

9.4 Appendix D

OH-continuous Print

- Format 1: For the printout result including interval and continuous printing mode of Check Weighing application

| Field | Weight (Right aligned) | Space | Unit (Right aligned) | Space | Stability (?) | Space | T/N/G/PT (Right aligned) | Space | Application Status (Right aligned) | Term. |
|--------|---------------------------|-------|-------------------------|-------|------------------|-------|-----------------------------|-------|--|-------|
| Length | 11 | 1 | 5 | 1 | 1 | 1 | 2 | 1 | 6 | 2 |

Note: **Application Status** is fixed to 6 characters. The printed status will be "Under", "Accept" and "Over" for check weighing.

- Format 2: For Non Check Weighing applications' printout result

| Field | Weight (Right aligned) | Space | Unit (Right aligned) | Space | Stability (?) | Space | T/N/G/PT (Right aligned) | Term. |
|--------|---------------------------|-------|-------------------------|-------|------------------|-------|-----------------------------|-------|
| Length | 11 | 1 | 5 | 1 | 1 | 1 | 2 | 2 |

LIMITED WARRANTY

OHAUS products are warranted against defects in materials and workmanship from the date of delivery through the duration of the warranty period. During the warranty period OHAUS will repair, or, at its option, replace any component(s) that proves to be defective at no charge, provided that the product is returned, freight prepaid, to OHAUS. This warranty does not apply if the product has been damaged by accident or misuse, exposed to radioactive or corrosive materials, has foreign material penetrating to the inside of the product, or as a result of service or modification by other than OHAUS. In lieu of a properly returned warranty registration card, the warranty period shall begin on the date of shipment to the authorized dealer. No other express or implied warranty is given by OHAUS Corporation. OHAUS Corporation shall not be liable for any consequential damages.

As warranty legislation differs from state to state and country to country, please contact OHAUS or your local OHAUS dealer for further details



Ohaus Corporation
7 Campus Drive
Suite 310
Parsippany, NJ 07054 USA
Tel: +1 973 377 9000
Fax: +1 973 944 7177

With offices worldwide / Con oficinas en todo el mundo / Avec des bureaux partout dans le monde / Mit Büros weltweit / Con
uffici in tutto il mondo
www.ohaus.com



P/N 30696592A © 2021 Ohaus Corporation, all rights reserved / todos los derechos reservados / tous droits réservés / alle
Rechte vorbehalten / tutti i diritti riservati