



TCBI500-2
TCBI700-2
TCBI350-2



Assemble TCBI Column

Assemblare il kit colonna PB
Ensamblar el kit de columna PB
PB-Säulen-Bausatz montieren
Assembler le kit de colonne PB
Montaż zestawu kolumn PB

1



2



Attach DFWX with DFXCL Mount


Fissare il DFWX con il supporto DFXCL

Fijar DFWX con soporte DFXCL

DFWX mit DFXCL-Montage befestigen

Fixer le DFWX avec la monture DFXCL

Mocowanie DFWX za pomocą uchwytu DFXCL



Attach 3590 with 3590CL Mount

Fissare il 3590 con il supporto 3590CL


Fije el 3590 con el soporte 3590CL

3590 mit 3590CL-Halterung befestigen


Fixer le 3590 avec la monture 3590CL

Mocowanie 3590 za pomocą uchwytu 3590CL


1




2



3



4



5

