



## Convenient way to test the torque of tools

### Features

- **1** Particularly suitable for testing torque wrenches, electric hand screwdrivers and cordless screwdrivers
- **2 Torque pick-up system** for dynamic testing of electric screwdrivers
- **Metal housing** for continuous use in tough environmental conditions
- **3 Capacity display:** A bar lights up to show how much of the measuring range is still available.
- **3 LCD graphics display** with backlight
- **Rubber feet with anti-slip feature** at SAUTER DB 0.5-4 up to DB 10-3
- **4 Stable mounting plate** for solid fixation at SAUTER DB 20-3 up to DB 500-2
- **USB and RS-232** data interfaces included
- Scope of delivery: Torque pick-up, sturdy carry case, mounting plate (models with [Max] ≥ 20 Nm)
- **Internal data memory** saves up to 500 measurements. The memory contents can be transferred to the PC using optional software
- **Peak hold function** to capture the peak value or **Track-Funktion** for continuous display of measurement
- Can be used in both directions of rotation
- **Limit value function**, programming of Max./Min., in pull and push direction, with output of acoustic and optical signal. Ideal mode for efficient and accurate testing of standard parts
- **AUTO-OFF function**


### Technical data

- **3** Backlit LCD graphics display
- Units can be selected:  
Nm, lbf-in, kgf-cm, kgf-m, ft-lbf
- Precision: ± 0,5 % of [Max]
- Measuring frequency: 1000 Hz
- Usable measuring range:  
5–100 % of [Max]
- Overload protection: 150 % of [Max]
- Rechargeable battery pack integrated, standard, operating time up to 18 h without backlight, charging time approx. 14 h
- Overall dimensions W×D×H 200×100×50 mm
- Net weight approx. 3 kg

### Accessories

- **Plug-In for data transfer of measuring data** from the measuring instrument and transfer to a PC, e.g. in Microsoft Excel®, SAUTER AFI-1.0
- **Force-time data transfer software** for graphical representation on the PC and data transfer to Microsoft Excel®, SAUTER AFH FAST

#### STANDARD



































#### OPTION



Model	Measuring range [Max] Nm	Readout [d] Nm	Tool fitting mm/Inch	Option Factory calibration certificate	
				KERN	
SAUTER					
DB 0.5-4	0,5	0,0001	20 mm & 3/8"	961-120	
DB 1-4	1	0,0002	20 mm & 3/8"	961-120	
DB 5-3	5	0,001	20 mm & 3/8"	961-120	
DB 10-3	10	0,002	20 mm & 3/8"	961-120	
DB 20-3	20	0,005	20 mm & 3/8"	961-120	
DB 50-2	50	0,01	20 mm & 3/8"	961-120	
DB 100-2	100	0,02	3/8"	961-120	
DB 200-2	200	0,05	1/2"	961-120	
DB 500-2	500	0,05	3/4"	961-120	

Datasheet\_DB\_V1



 CAL EXT	<b>Adjusting program (CAL):</b> For quick setting of the balance's accuracy. External adjusting weight required.	 SWITCH	<b>Control outputs (optocoupler, digital I/O):</b> to connect relays, signal lamps, valves, etc.	 230 V	<b>Mains adapter:</b> 230V/50Hz in standard version for EU. On request GB, AUS or USA version available.
 CAL BLOCK	<b>Calibration block:</b> standard for adjusting or correcting the measuring device.	 ANALOG	<b>Analogue interface:</b> to connect a suitable peripheral device for analogue processing of the measurements.	 230 V	<b>Power supply:</b> Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request.
 PEAK	<b>Peak hold function:</b> capturing a peak value within a measuring process.	 STATISTIC	<b>Statistics:</b> using the saved values, the device calculates statistical data, such as average value, standard deviation etc.	 ELECTRO	<b>Motorised drive:</b> The mechanical movement is carried out by a electric motor.
 SCAN	<b>Scan mode:</b> continuous capture and display of measurements.	 SOFTWARE	<b>PC Software:</b> to transfer the measurements from the device to a PC.	 STEPPER	<b>Motorised drive:</b> The mechanical movement is carried out by a synchronous motor (stepper).
 PUSH/PULL	<b>Push and Pull:</b> the measuring device can capture tension and compression forces.	 PRINT	<b>Printer:</b> a printer can be connected to the device to print out the measurements.	 FAST-MOVE	<b>Fast-Move:</b> the total length of travel can be covered by a single lever movement.
 SCALE	<b>Length measurement:</b> captures the geometric dimensions of a test object or the movement during a test process.	 GLP PROTOCOL	<b>GLP/ISO record keeping:</b> of measurements with date, time and serial number. Only with SAUTER printers.	 DAkkS +3 DAYS	<b>DAkkS calibration possible:</b> The time required for DAkkS calibration is shown in days in the pictogram.
 FOCUS	<b>Focus function:</b> increases the measuring accuracy of a device within a defined measuring range.	 UNIT	<b>Measuring units:</b> Weighing units can be switched to e.g. non-metric at the touch of a key. Please refer to website for more details.	 ISO +4 DAYS	<b>Factory calibration:</b> The time required for factory calibration is specified in the pictogram.
 MEMORY	<b>Internal memory:</b> to save measurements in the device memory.	 TOL	<b>Measuring with tolerance range:</b> Upper and lower limiting can be programmed individually, e.g. for sorting and dosing.	 DAYS	<b>Package shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram.
 RS 232	<b>Data interface RS-232:</b> bidirectional, for connection of printer and PC.	 ZERO	<b>ZERO:</b> Resets the display to "0".	 1 DAY	<b>Pallet shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram.
 USB	<b>Data interface USB:</b> To connect the balance to a printer, PC or other peripheral devices.	 BATT	<b>Battery operation:</b> Ready for battery operation. The battery type is specified for each device.	 2 YEARS WARRANTY	<b>Warranty:</b> The warranty period is shown in the pictogram.
 IR	<b>Data interface Infrared:</b> To transfer data from the balance to a printer, PC or other peripheral devices.	 ACCU	<b>Rechargeable battery pack:</b> rechargeable set.		

**Your SAUTER specialist dealer:**